



**PARTS
CATALOGUE
CATALOGUE
DE PIÈCES DÉTACHÉES**

F9.9JMH'16 (6DR4)
F9.9JE'16 (6DR4)

F9.9JMH/F9.9JE
PARTS CATALOGUE
©2016 by Yamaha Motor Co., Ltd.
1st edition, January 2016
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

F9.9JMH/F9.9JE
CATALOGUE DE PIECES DETACHEES
©2016 par Yamaha Motor Co., Ltd.
1^{re} édition, janvier 2016
Tous droits réservés
Toute réimpression ou utilisation
non autorisée sans la permission écrite
de la Yamaha Motor Co., Ltd.
est formellement interdite.
Imprimé au Japon

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

“UR” Use specified parts number.

“UN” Use as many as needed.

“AP” Alternate Parts

“LM” Locally Made (Parts need to be ordered locally)

“F#” Frame No. (Applicable machine No.)

“O/S” Over Size

3. The number of components for assembly

- Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
- The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.



PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



8. Applicable Engine Starting Serial No.

Model	Serial No.	Model	Serial No.
F9.9J	6AUK-1048364		

9. Applicable Colour Code

Abbreviation	Colour Name	Colour Code
DBN1	DARK BLUISH GRAY 1	008D

10. Quantity Column Information

Column No.	Name Of Q'ty Column	Applicable Model
1	MH	F9.9JMH
2	E	F9.9JE

AVANT-PROPOS

Ce catalogue de pièces détachées concerne les pièces pour le(s) modèle(s) indiqué(s) sur la page de couverture. Lorsque vous commandez des pièces de rechange, veuillez vous référer à ce catalogue de pièces détachées et indiquer clairement les numéros et les noms des pièces détachées.

1. Les modifications ou ajouts ayant été effectués après la parution du catalogue de pièces détachées seront décrits dans les Bulletins d'information concernant les pièces détachées.
Il est recommandé que vous apportiez les corrections nécessaires au catalogue des pièces détachées en vous référant aux Bulletins d'information.

2. Abréviations

Dans ce catalogue, les abréviations suivantes sont utilisées:

“UR” Utiliser le numéro de pièces spécifié.

“UN” Utiliser autant que nécessaire.

“AP” Pièces de substitution

“LM” Fabrication locale (les pièces doivent être commandées localement.)

“F#” N° de cadre (applicable au N° de série)

“O/S” Surdimensionné

3. Nombre de pièces d'un assemblage

- Les pièces fournies comme composants d'un assemblage sont précédées d'un point (.) de la manière indiquée ci-dessous.
- Le chiffre apparaissant à la droite de chaque composant indique la quantité de pièces pour chaque unité d'assemblage.

N° PIECES	DESCRIPTION	QTE	REMARQUES
2F5-83310-60	ENS. CLIGNOTANT AVANT	2	
115-83311-60	.AMPOULE (6V-18W)	1	

4. Les couleurs concernant les graphiques sont indiquées dans la colonne “REMARQUES”, comme indiqué ci-dessous.



N° PIECES	DESCRIPTION	QTE	REMARQUES
2N4-24110-00-X5	RESERVOIR A ESSENCE.	2	MXR
3J1-24240-10	.GRAPHIQUE	1	POUR MXR

5. Veuillez noter que les illustrations sont indiquées à titre de référence pour trouver les numéros de pièces, non pour être utilisées lors de l'assemblage. Lors de l'assemblage, veuillez utiliser le manuel d'entretien adéquat.

6. L'astérisque (*) placé devant un numéro de référence indique des éléments qui ont été modifiés après la première édition.

7. N° de série applicable

N° de Série du moteur



8. N° de série initial du moteur applicable

Modèle	N° de série	Modèle	N° de série
F9.9J	6AUK-1048364		

9. Code couleur applicable

Abréviation	Nom de la couleur	Code couleur
DBN1	DARK BLUISH GRAY 1	008D

10. Informations relatives à la colonne Quantité

N° de la colonne	Nom de la colonne Qté	Modèle applicable
1	MH	F9.9JMH
2	E	F9.9JE

CONTENTS

SCHEDULED SERVICE PARTS.....	1
TOP COWLING.....	2
CYLINDER & CRANKCASE 1.....	3
CRANKSHAFT & PISTON.....	4
CYLINDER & CRANKCASE 2.....	5
VALVE.....	6
INTAKE.....	7
CARBURETOR.....	9
OIL PUMP.....	11
FUEL.....	12
STARTER.....	14
GENERATOR.....	16
ELECTRICAL 1.....	17
ELECTRICAL 2.....	18
STARTING MOTOR.....	19
BOTTOM COWLING.....	20
STEERING.....	23
STEERING FRICTION.....	25
CONTROL 1.....	26
CONTROL 2.....	28
REMO CON ATTACHMENT.....	30
BRACKET 1.....	31
BRACKET 2.....	33
UPPER CASING.....	34
OIL PAN.....	35
LOWER CASING & DRIVE 1.....	36
LOWER CASING & DRIVE 2.....	39
FUEL TANK.....	40
STEERING GUIDE.....	41
REMOTE CONTROL BOX.....	42
REMOTE CONTROL ASSY.....	43
OPTIONAL PARTS 1.....	46
OPTIONAL PARTS 2.....	48
OPTIONAL PARTS 3.....	49
REPAIR KIT 1.....	50
REPAIR KIT 2.....	51
REPAIR KIT 3.....	52

INDEX


NUMERICAL INDEX.....	53
----------------------	----

TABLE DES MATIERES

PIECES MAINTENANCE PERIODIQUE.....	1
CAPOT SUPERIEUR.....	2
CYLINDRE & CARTER 1.....	3
VILEBREQUIN & PISTON.....	4
CYLINDRE & CARTER 2.....	5
SOUPAPE.....	6
ADMISSION.....	7
CARBURATEUR.....	9
POMPE A HUILE.....	11
CARBURANT.....	12
DEMARREUR.....	14
GENERATRICE.....	16
PARTIE ELECTRIQUE 1.....	17
PARTIE ELECTRIQUE 2.....	18
DEMARREUR ELECTRIQUE.....	19
CAPOT INFERIEUR.....	20
DIRECTION.....	23
CUVETTE POIGNEE DE DIRECTION.....	25
COMMANDE 1.....	26
COMMANDE 2.....	28
COMMANDE A DISTANCE.....	30
SUPPORT 1.....	31
SUPPORT 2.....	33
FOURREAU.....	34
VENTILATEUR D'HUILE.....	35
BOITIER D'HELICE TRANSMISSION1.....	36
BOITIER D'HELICE TRANSMISSION2.....	39
RESERVOIR A CARBURANT.....	40
FIXATION DE DIRECTION.....	41
BOITIER DE COMMANDE A DISTANCE.....	42
BOITIER DE COMMANDE A DISTANCE.....	43
PIECES OPTIONNELLES 1.....	46
PIECES OPTIONNELLES 2.....	48
PIECES OPTIONNELLES 3.....	49
KITS DE REPARATION 1.....	50
KITS DE REPARATION 2.....	51
KITS DE REPARATION 3.....	52

INDEX

INDEX NUMERIQUE.....	53
----------------------	----




FWD
6DR2100-N010

FIG. 1 SCHEDULED SERVICE PARTS

PIECES MAINTENANCE PERIODIQUE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	U				REMARKS REMARQUES
1	66M-12411-01	THERMOSTAT	1	1				
2	6G8-12414-A0	THERMOSTAT GASKET, COVER JOINT, COUVERCLE	1	1				
3	6G8-11325-00	ANODE	1	1				
4	94702-00274	ANODE						
5	68T-24251-01	PLUG, SPARK (NGK BR6HS-10)	2	2				
6	90430-10M11	BOUGIE D'ALLUMAGE(NGK BR6HS-10)	1	1				
7	68T-45251-00	STRAINER 1	1	1				
8	90430-08003	FILTRE 1						
9	68T-W0078-00	GASKET JOINT	1	1				
		ANODE	1	1				
		ANODE						
		GASKET JOINT	2	2				
		WATER PUMP REPAIR KIT	1	1				
		KIT DE REPARATION DE LA POMPE						



6DR2300-N020

FIG. 2 TOP COWLING

CAPOT SUPERIEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	MH	U				REMARKS REMARQUES
1	6DR-42610-00	TOP COWLING ASSY CAPOT (ENS.)	1					
	6DR-42610-10	TOP COWLING ASSY CAPOT (ENS.)		1				
2	6DR-4261A-00	.TOP COWLING W/O GRAPHICS .CAPOT SUPERIEUR SANS GRAPHIQUE	1					
	6DR-4261A-10	.TOP COWLING W/O GRAPHICS .CAPOT SUPERIEUR SANS GRAPHIQUE		1				
3	6DR-42613-00	.MOLDING, AIR DUCT .MANCHON A AIR	1	1				
4	90167-05017	..SCREW, TAPPING ..VIS, TETE FRAISEE	4	4				
5	6DR-42651-00	..HOOK ..CROCHET	1	1				
6	90266-04005	..RIVET ..RIVET	2	2				
7	6DR-42649-00	..HOLDER, CLAMP BAND ..SUPPORT, SANDOW DE SERRAGE	1	1				
8	6BG-42662-00	..DAMPER ..AMORTISSEUR	2	2				
9	60R-42615-00	..SEAL ..JOINT	1	1				
10	60R-42652-00	..HOOK ..CROCHET	1	1				
11	97595-05514	..BOLT, WITH WASHER ..VIS HEXAGONAL AVC RONDELLE	2	2				
12	68T-42649-00	..HOLDER, CLAMP BAND ..SUPPORT, SANDOW DE SERRAGE	1	1				
13	6AH-42697-10	..TUNING FORK MARK ..MARQUE, YAMAHA	1	1				
14	6AU-42678-10	..GRAPHIC, REAR ..ADHESIF, ARRIERE	1	1				
15	60R-42675-00	..GRAPHIC, SIDE 1 ..EMBLEME	1	1				
16	60R-42676-10	..GRAPHIC, SIDE 2 ..EMBLEME	1	1				
17	6AU-42678-10	..GRAPHIC, REAR ..ADHESIF, ARRIERE		1				





FIG. 3 CYLINDER & CRANKCASE 1

CYLINDRE & CARTER 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W				REMARKS REMARQUES
1	6AU-W009B-00-1S	CYLINDER BLOCK ASSY CYLINDRE GROUPE (ENS.)	1	1				
2	6AU-15100-00	CRANKCASE ASSY CARTER DE MOTEUR COMPLET	1	1				
3	99530-12016	.PIN, DOWEL .GOUJON, D'ASSEMBLAGE	4	4				
4	90119-08M29	BOLT, WITH WASHER BOULON, AVEC RONDELLE	6	6				
5	68T-11351-00	GASKET, CYLINDER JOINT, D'EMBASE	1	1				
6	66M-12411-01	THERMOSTAT THERMOSTAT	1	1				
7	688-12412-00	.SEAL, THERMOSTAT .JOINT, THERMOSTAT	1	1				
8	68T-12413-00-1S	COVER, THERMOSTAT COUVERCLE, THERMOSTAT	1	1				
9	6G8-12414-A0	GASKET, COVER JOINT, COUVERCLE	1	1				
10	90119-06MA2	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2	2				
11	68T-12481-00	PIPE 1 DURITE 1	1	1				
12	90465-11M10	CLAMP BRIDE	2	2				
13	6AU-41113-00-1S	OUTER COVER, EXHAUST COUVERCLE, ECHAPPEMENT	1	1				
14	68T-41114-A0	GASKET, EXHAUST OUTER COVER JOINT, COUVERCLE D'ECHAPPEMENT	1	1				
15	90119-06MA3	BOLT, WITH WASHER BOULON, AVEC RONDELLE	5	5				
16	68T-12482-00	PIPE 2 DURITE 2	1	1				
17	90467-10M04	CLIP JONC	1	1				
18	90465-11M10	CLAMP BRIDE	1	1				




6DR1100-M040

FIG. 4 CRANKSHAFT & PISTON

VILEBREQUIN & PISTON

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	MHT	W				REMARKS REMARQUES
1	6AU-11411-00	CRANKSHAFT VILEBREQUIN COMPLET	1	1				
2	68T-11416-01	PLANE BEARING, CRANKSHAFT 1 COUSSINET DE VILEBREQUIN 1	4	4				UR BROWN UR BROWN
	68T-11416-11	PLANE BEARING, CRANKSHAFT 1 COUSSINET DE VILEBREQUIN 1	4	4				UR BLACK UR BLACK
	68T-11416-21	PLANE BEARING, CRANKSHAFT 1 COUSSINET DE VILEBREQUIN 1	4	4				UR BLUE UR BLUE
3	6AU-11650-00	CONNECTING ROD ASSY BIELLE COMPLETE	2	2				
4	67D-11654-00	.BOLT, CONNECTING ROD .BOULON, BIELLE	2	2				
5	6AU-11631-00-96	PISTON (STD) PISTON (STD)	2	2				
	6AU-11635-00	PISTON (0.25MM O/S) PISTON (0.25MM O/S)	2	2				AP AP
	6AU-11636-00	PISTON (0.50MM O/S) PISTON (0.50MM O/S)	2	2				AP AP
6	68T-11603-01	PISTON RING SET (STD) JEU DE SEGMENTS (STD)	2	2				
	68T-11604-01	PISTON RING SET (0.25MM O/S) JEU DE SEGMENTS (0.25MM O/S)	2	2				AP AP
	68T-11605-01	PISTON RING SET (0.50MM O/S) JEU DE SEGMENTS (0.50MM O/S)	2	2				AP AP
7	68T-11633-00	PIN, PISTON AXE, PISTON	2	2				
8	93450-15023	CIRCLIP CIRCLIP, TYPE S	4	4				
9	93102-30M22	OIL SEAL JOINT SPY	1	1				
10	93101-25M69	OIL SEAL JOINT SPY	1	1				




FIG. 5 CYLINDER & CRANKCASE 2

CYLINDRE & CARTER 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W				REMARKS REMARQUES
1	6AU-W009A-01-1S	CYLINDER HEAD COMPLETE CULASSE (ENS.)	1	1				
2	6AU-11111-00-1S	HEAD, CYLINDER 1 CULASSE	1	1				
3	6AU-11133-10	.GUIDE, VALVE 1 .GUIDE, SOUPAPE 1	4	4				
4	68T-11181-00	GASKET, CYLINDER HEAD 1 JOINT, DE CULASSE 1	1	1				
5	99530-10114	PIN, DOWEL GOUJON, D'ASSEMBLAGE	2	2				
6	90105-08M36	BOLT, FLANGE BOULON	2	2				
7	90105-08M78	BOLT, FLANGE BOULON	4	4				
8	90119-06049	BOLT, WITH WASHER BOULON, AVEC RONDELLE	3	3				
9	68T-11191-00-1S	COVER, CYLINDER HEAD 1 COUVERCLE, CULASSE 1	1	1				
10	650-24378-00	.PIPE, JOINT 4 .DURITE RACCORDEMENT 3	1	1				
11	68T-11356-00	SEAL, CYLINDER 2 JOINT, SPY CYLINDRE	1	1				
12	97095-06020	BOLT BOULON	4	4				
13	92995-06600	WASHER RONDELLE	4	4				
14	68T-11168-00	COVER, BREATHER COUVERCLE, RENIFLARD	1	1				
15	68T-11169-A0	GASKET, BREATHER COVER JOINT, COUVERCLE DE RENIFLARD	1	1				
16	98507-04010	SCREW, PAN HEAD VIS, TETE TRONCONIQUE	5	5				
17	92907-04600	WASHER RONDELLE	5	5				
18	6G8-11325-00	ANODE ANODE	1	1				
19	98980-05025	SCREW, BIND VIS, DE PRESSION	1	1				
20	6G8-11197-A0	PLUG, BLIND PLOT, BORGNE	1	1				
21	93210-13M63	O-RING JOINT TORIQUE	1	1				
22	6G8-15363-00	PLUG, OIL PLOT, HUILE	1	1				
23	93210-24M79	O-RING JOINT TORIQUE	1	1				
24	94702-00274	PLUG, SPARK (NGK BR6HS-10) BOUGIE D'ALLUMAGE(NGK BR6HS-10)	2	2				





FIG. 6 VALVE

SOUPAPE

[illegible]



6DR4300-Q070

FIG. 7 INTAKE

ADMISSION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W		REMARKS REMARQUES
1	68T-13641-01-1S	MANIFOLD, INTAKE 1	1			FOR RUS
	68T-13641-20-1S	TUBULURE, ADMISSION 1	1	1		FOR RUS
2	650-24378-00	.PIPE, JOINT 4	1			EUR-FLUSHING KIT
	67F-12482-00	.DURITE RACCORDEMENT 3	1	1		FOR RUS
		.PIPE 2	1	1		FOR RUS
		.DURITE 2	1	1		EUR-FLUSHING KIT
3	68T-13645-00	GASKET, MANIFOLD 1	1	1		EUR-FLUSHING KIT
		JOINT, TUBULURE 1				
4	90119-06MA5	BOLT, WITH WASHER	3	3		
		BOULON, AVEC RONDELLE				
5	90119-06MA3	BOLT, WITH WASHER	2	2		
		BOULON, AVEC RONDELLE				
6	91690-50014	PIN, SPRING	2	2		
		AGRAFFE				
7	90445-09074	HOSE (L130)	1			FOR RUS
		DURITE (L130)				FOR RUS
	90445-09M20	HOSE (L95)	1	1		EUR-FLUSHING KIT
		DURITE (L95)				EUR-FLUSHING KIT
8	68T-13646-A0	GASKET, MANIFOLD 2	2	2		
		JOINT, TUBULURE 2				
9	68T-14271-00	INSULATOR	1	1		
		ISOLATEUR				
10	6AU-14440-00	SILENCER ASSY, INTAKE	1	1		
		SIENCIEUX D'ADMISSION				
11	93210-31MJ5	O-RING	1	1		
		JOINT TORIQUE				
12	90387-06M70	COLLAR	2	2		
		COLLERETTE				
13	90105-06188	BOLT, FLANGE	2	2		
		BOULON				
14	68T-12483-00	PIPE 3	1	1		
		DURITE 3				
15	90465-08M99	CLAMP	1	1		
		BRIDE				
16	90465-08M83	CLAMP	1	1		EUR-FLUSHING KIT
		BRIDE				EUR-FLUSHING KIT
17	97595-06510	BOLT, WITH WASHER	1			EUR-FLUSHING KIT
		VIS HEXAGONAL AVC RONDELLE				EUR-FLUSHING KIT
18	6H4-41271-02	KNOB, CHOKE	1			
		BOUTON DE STARTER				
19	689-41273-00	GROMMET	1			
		PASSE-FIL				
20	68T-41256-00	ROD, CHOKE 1	1			
		TRINGLE 1, STARTER				
21	6J8-41262-00	JOINT, CHOKE LEVER	1			
		RACCORD, LEVIER DE STARTER				
22	90467-08M18	CLIP	1	1		
		JONC				
23	90465-11M10	CLAMP	1	1		
		BRIDE				
24	68T-13641-20-1S	MANIFOLD, INTAKE 1	1			AP RUS-FLUSHING HQ
		TUBULURE, ADMISSION 1				AP RUS-FLUSHING HQ




FIG. 7 INTAKE

ADMISSION

[illegible]





FIG. 8 CARBURETOR

CARBURATEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W				REMARKS REMARQUES
1	6DR-14301-22	CARBURETOR ASSY 1 CARBURATEUR COMPLET 1	1					
	6DR-14301-52	CARBURETOR ASSY 1 CARBURATEUR COMPLET 1		1				
2	69W-14321-00	.SCREW, THROTTLE .VIS, ACCELERATEUR	1	1				
3	62Y-14212-00	.SPRING, PILOT ADJUSTING .RESSORT, VIS DE RALENTI	1	1				
4	6DR-14321-00	.SCREW, THROTTLE .VIS, ACCELERATEUR	3	3				
5	62Y-14321-00	.SCREW, THROTTLE .VIS, ACCELERATEUR	2	2				
6	6DR-14385-00	.FLOAT .FLOTTEUR	1	1				
7	6DR-1432A-00	.PLUG .PLOT	1	1				
8	6DR-14561-00	.O-RING .JOINT TORIQUE	1	1				
9	4FP-14386-00	.PIN, FLOAT .AXE, FLOTTEUR	1	1				
10	6DR-14336-00	.NEEDLE .AIGUILLE	1	1				
11	6DR-14343-46	.JET, MAIN (#92) .GICLÉUR, PRINCIPAL (#92)	1	1				
12	6DR-14342-71	.JET, PILOT (#43) .GICLÉUR, RALENTI (#43)	1	1				
13	6DR-14341-00	.NOZZLE, MAIN .PUITS D'AIGUILLE	1	1				
14	6DR-14381-00	.BODY, FLOAT CHAMBER .CORPS, CUVE DE FLOTTEUR	1	1				
15	6DR-14984-00	.GASKET, FLOAT CHAMBER .JOINT, CUVE DE FLOTTEUR	1	1				
16	62Y-14383-30	.SCREW, DRAIN .BOUCHON, PURGE	1	1				
17	652-14397-00	.O-RING .JOINT TORIQUE	1	1				
18	6DR-14216-00	.SCREW .VIS	1	1				
19	6DR-14860-00	.CHECK VALVE ASSY .SOUPAPE, RETENUE COMPLET	1	1				
20	6DR-14680-00	.STOPPER .BUTÉE	1	1				
21	6DR-14147-00	.O-RING .JOINT TORIQUE	1	1				
22	6DR-14335-00	.SPRING, PLUNGER .RESSORT, PLONGEUR	1	1				
23	6DR-14371-00	.PLUNGER, STARTER .PLONGEUR, STARTER	1	1				
24	6DR-14323-10	.SCREW, AIR ADJUSTING .VIS DE DOSEUR D'AIR	1	1				
25	6DR-14334-00	.SPRING, AIR ADJUSTING .RESSORT, VIS DE DOSEUR D'AIR	1	1				
26	6DR-14285-00	.WASHER .RONDELLE	1	1				



FWD
6DR4300-Q090

FIG. 9 OIL PUMP

POMPE A HUILE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	U				REMARKS REMARQUES
1	68T-12171-00	CAMSHAFT 1 ARBRE A CAMES 1	1	1				
2	66M-11537-00	GEAR, DRIVEN PIGNON SECONDAIRE	1	1				
3	90105-06M14	BOLT FLANGE BOULON	1	1				
4	90201-13201	WASHER, PLATE RONDELLE, PLATE	1	1				
5	90201-06M94	WASHER, PLATE RONDELLE, PLATE	1	1				
6	68T-46241-00	BELT COURROIE TRAPEZOIDALE	1	1				
7	68T-11536-00	GEAR, DRIVE ENGRENAGE, MENANT	1	1				
8	68T-11557-00	WASHER 1 RONDELLE 1	1	1				
9	6G8-11587-01	WASHER, LOCK RONDELLE, FREIN	1	1				
10	90170-24M09	NUT ECROU	1	1				
11	90280-03M01	KEY, WOODRUFF CLAVETTE, DEMI-LUNE	2	2				
12	6AU-46297-00	COVER, DUST COUVERCLE, POUSSIERE	1	1				
13	90480-10627	GROMMET PASSE-FIL	3	3				
14	68T-13300-00	OIL PUMP ASSY POMPE A HUILE COMPLETE	1	1				
15	68T-13329-00	GASKET, PUMP COVER JOINT, COUVERCLE DE POMPE	1	1				
16	97595-06530	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	3	3				
17	93102-18M21	OIL SEAL JOINT SPY	1	1				





FIG. 10 FUEL

CARBURANT

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W				REMARKS REMARQUES
1	6G1-24304-10	FUEL PIPE JOINT COMP. 1 DURITE RACCORDEMT. A ESSENCE	1	1				
2	61N-24329-00	SEAL JOINT	1	1				
3	97095-06025	BOLT BOULON	1	1				
4	92995-06600	WASHER RONDELLE	1	1				
5	90445-10046	HOSE (L295) DURITE (L295)	1	1				
6	90465-11M10	CLAMP BRIDE	1	1				
7	90467-09M09	CLIP JONC	2	2				
8	68T-24251-01	STRAINER 1 FILTRE 1	1	1				
9	90445-10M50	HOSE (L170) DURITE (L170)	1	1				
10	90467-09M09	CLIP JONC	2	2				
11	90445-16010	HOSE (L140) DURITE (L140)	1	1				
12	68T-24410-01	FUEL PUMP ASSY POMPE A ESSENCE	1	1				
13	66M-24413-01	.BODY 2 .CORPS 2	1	1				
14	6A0-24421-01	.VALVE, CHECK .SOUPAPE, RETENUE	2	2				
15	6E7-14325-00	.SCREW, PAN HEAD .VIS TETE CONIQUE	2	2				
16	66M-24411-01	.DIAPHRAGM .DIAPHRAGME	1	1				
17	66M-24423-00	.SPRING, DIAPHRAGM .RESSORT, DIAPHRAGME	1	1				
18	66M-13131-00	.PLUNGER .PLONGEUR	1	1				
19	66M-24374-00	.PIN .GOUPILLE	1	1				
20	66M-24454-00	.SPRING .RESSORT	1	1				
21	66M-24471-01	.DIAPHRAGM .DIAPHRAGME	1	1				
22	66M-24444-00	.SCREW .VIS	4	4				
23	95380-04600	.NUT .ECROU	4	4				
24	97595-06630	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	2	2				
25	93210-20M65	O-RING JOINT TORIQUE	1	1				
26	6AU-24311-00	PIPE, FUEL 1 DURITE A ESSENCE	1	1				
27	90467-09M09	CLIP JONC	2	2				




6DR1300-M101

FIG. 10 FUEL

CARBURANT

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W				REMARKS REMARQUES
28	90447-13014	TUBE DURITE	1	1				
29	90464-10M53	CLAMP BRIDE	1	1				
30	68T-28100-00	TOOL KIT TROUSSE A OUTILS	1	1				AP AP
31	6DR-28199-73-E0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (E) UR (E)
	6DR-28199-73-F0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (F) UR (F)
	6DR-28199-73-S0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (ES) UR (ES)
	6DR-28199-73-G0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (D) UR (D)
	6DR-28199-73-D0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (NL) UR (NL)
	6DR-28199-73-H0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (I) UR (I)
32	6DR-28199-83-K0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (DK) UR (DK)
	6DR-28199-83-R0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (GR) UR (GR)
	6DR-28199-83-P0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (P) UR (P)
	6DR-28199-83-N0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (N) UR (N)
	6DR-28199-83-M0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (S) UR (S)
	6DR-28199-83-L0	MANUAL, OWNER'S MANUEL D'UTILISATION	1	1				UR (SF) UR (SF)



6DR1300-M110


*1: CUT FROM 50M ROLLS, PART NO. 90890-44373, CUTTING LENGTH 1.8M

*1: A PRELEVER SUR BOBINE 50M, REFERENCE 90890-44373, LONGUEUR DE COUPE 1.8M

FIG. 11 STARTER

DEMARREUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	E			REMARKS REMARQUES
1	68T-15710-13	STARTER ASSY DEMARREUR COMPLET	1				
2	68T-15711-03	.CASE, STARTER .CARTER DE DEMARREUR	1				
3	68T-15795-00	.GUIDE, ROPE .GUIDE DE CABLE	1				
4	63V-15714-00	.DRUM, SHEAVE .TAMBOUR, POULIE	1				
5	63V-15741-00	.PAWL, DRIVE .CLIQUET, ENTRAINEMENT	1				
6	63V-15713-00	.SPRING, STARTER .RESSORT DE DEMARREUR	1				
7	68T-15716-00	.PLATE, DRIVE .PLAQUE, ENTRAINEMENT	1				
8	63V-15705-01	.SPRING, DRIVE PAWL .RESSORT DE CLIQUET	1				
9	63V-15767-01	.SPRING .RESSORT	1				
10	68T-15784-00	.SPRING, RETURN .RESSORT, RAPPEL	1				
11	63V-15744-00	.CIRCLIP .CIRCLIP	1				
12	68T-15793-00	.SCREW .VIS	1				
13	68T-15764-00	.COLLAR 1 .COLLERETTE 1	1				
14	6G1-15755-00	.HANDLE, STARTER .POIGNEE, DE DEMARREUR	1				
15	*	.WIRE, STARTER (L:1800MM) .CABLE DE DEMARREUR (L:1800MM)	1				*1 *1
16	6G1-15779-00	.COVER .COUVERCLE	1				
17	6A0-15789-00	.DAMPER .AMORTISSEUR	1				
18	68T-15794-00	.STOPPER .BUTEE	1				
19	66T-15734-00	.SPRING, RETURN .RESSORT, RAPPEL	1				
20	68T-15770-00	.CABLE COMP., STARTER STOP .CABLE, BUTEE DE DEMAR	1				
21	66T-15731-00	.SPRING, RETURN .RESSORT, RAPPEL	1				
22	97095-06020	BOLT BOULON	3				
23	92995-06600	WASHER RONDELLE	3				
24	68T-15762-00	SEAL, RUBBER 2 JOINT CAOUTCHOUC 2	1				
25	6EE-81995-40	LABEL, WARNING ETIQUETTE, AVERTISSEMENT	1				
26	6EE-81995-50	LABEL, WARNING ETIQUETTE, AVERTISSEMENT	1				
27	6AU-13437-60	MARK, CAUTION MAKER	1				



6DR1300-M120

FIG. 12 GENERATOR

GENERATRICE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W				REMARKS REMARQUES
1	6DR-85550-10	ROTOR ASSY ROTOR CPLT	1	1				
2	68T-85520-00	COIL, CHARGE BOBINE, CHARGE	1	1				
3	68T-85580-01	COIL, PULSER BOBINE, PULSEUR	1	1				
4	68T-85533-10	COIL, LIGHTING BOBINE, ECLAIRAGE	1	1				
5	6H2-85582-00	ATTACHMENT, PULSER SUPPORT, PULSEUR	1	1				
6	90119-06014	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2	2				
7	97095-05010	BOLT BOULON	2	2				
8	90119-06MA1	BOLT, WITH WASHER BOULON, AVEC RONDELLE	4	4				
9	90465-11M10	CLAMP BRIDE	1	1				
10	90280-04M06	KEY, WOODRUFF CLAVETTE, DEMI-LUNE	1	1				
11	90170-12066	NUT ECROU	1	1				
12	90201-12472	WASHER, PLATE RONDELLE, PLATE	1	1				
13	6AV-81337-00	COVER, FLYWHEEL COUVERCLE, VOLANT		1				
14	97095-06020	BOLT BOULON		3				
15	92995-06600	WASHER RONDELLE		3				
16	6EE-81995-40	LABEL, WARNING ETIQUETTE, AVERTISSEMENT		1				
17	6EE-81995-50	LABEL, WARNING ETIQUETTE, AVERTISSEMENT		1				
18	6AU-13437-60	MARK, CAUTION MARKER		1				
19	68T-85711-60	MARK, CAUTION MARKER		1				
20	6EE-81994-40	LABEL, SAFETY ETIQUETTE, SECURITE		1				
21	6EE-81994-50	LABEL, SAFETY ETIQUETTE, SECURITE		1				
22	6AG-81996-00	MARK MARQUE		1				





FIG. 14 ELECTRICAL 2

PARTIE ELECTRIQUE 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	U			REMARKS REMARQUES
1	69G-82580-00	WIRE HARNESS ASSY 2 FAISCEAU DE FILS 2 CPLT		1			
2	69G-82105-01	.BATTERY CABLE (L: 3.0M) .CABLE DE BATTERIE (L: 3.0M)		1			
3	68T-42724-40	.GROMMET .PASSE-FIL		1			
4	6G8-82117-00	WIRE, LEAD FIL		1			
5	90446-10M86	HOSE (L140) DURITE (L140)		1			
6	68T-81940-00	STARTER RELAY ASSY LANCEUR RELAIS (ENS.)		1			
7	97595-06610	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE		2			
8	68T-81945-01	PLATE, SWITCH FITTING PLAQUE, FIXATION DU RELAIS		1			
9	97095-06012	BOLT BOULON		1			
10	92995-06600	WASHER RONDELLE		1			
11	90465-12M56	CLAMP BRIDE		1			
12	68T-86112-00	STAY, SOLENOID SUPPORT, SOLENOIDE		1			
13	90480-13018	GROMMET PASSE-FIL		1			
14	97095-06012	BOLT BOULON		2			
15	92995-06600	WASHER RONDELLE		2			
16	68T-86111-00	COIL, SOLENOID BOBINE		1			
17	68T-41237-00	JOINT, LINK RACCORD		1			
18	91690-30010	PIN, SPRING AGRAFFE		1			
19	97880-04008	SCREW, PAN HEAD VIS, TETE TRONCONIQUE		4			
20	92990-04600	WASHER, PLATE RONDELLE, PLATE		4			
21	68T-86117-00	HOOK, WIRE PULL CROCHET, TENSION DE CABLE		1			
22	93210-03261	O-RING JOINT TORIQUE		1			
23	68T-82150-00	FUSE HOLDER ASSY SUPPORT DE FUSIBLE		1			
24	66V-82151-00	.FUSE (10A-BL) .FUSIBLE (10A-BL)		2			
25	68T-82171-01	STAY, FUSE BOX SUPPORT, BOITE A FUSIBLES		1			
26	67F-2812A-00	PULLER, FUSE TENDEUR, FUSIBLE		1			




 6AU1100-G160

FIG. 15 STARTING MOTOR

DEMARREUR ELECTRIQUE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	MH	W			REMARKS REMARQUES
1	68T-81822-01	BRACKET, STARTING MOTOR SUPPORT, DEMARREUR ELECTRIQUE	1	1			
2	90119-08046	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2	2			
3	90119-08020	BOLT, WITH WASHER BOULON, AVEC RONDELLE	1	1			
4	68T-81800-00	STARTING MOTOR ASSY DEMARREUR ELECTRIQUE COMPLET		1			
5	68T-81857-00	.PINION STOPPER SET .BUTEE PIGNON		1			
6	689-81807-12	.GEAR ASSY, STARTING MOTOR .PIGNON, DEMARREUR ELECTRIQUE		1			
7	6F5-81830-10	.FRONT BRACKET ASSY .SUPPORT AVANT		1			
8	689-81831-00	.METAL, FRONT .METAL, AVANT		1			
9	689-81847-11	.O-RING .JOINT TORIQUE		2			
10	689-81809-11	.WASHER KIT .JEU DE RONDELLES		1			
11	689-81850-11	.ARMATURE ASSY .INDUIT		1			
12	689-81810-11	.STATOR ASSY .STATOR COMPLET		1			
13	689-81840-11	.BRUSH HOLDER ASSY .SUPPORT DE CHARBON		1			
14	689-81811-11	.BRUSH 1 .CHARBON 1		1			
15	689-81812-11	.BRUSH 2 .CHARBON 2		1			
16	689-81813-10	.SPRING, BRUSH .RESSORT, DE CHARBON		2			
17	689-81820-11	.REAR BRACKET ASSY .SUPPORT ARRIERE COMPLET		1			
18	689-81826-10	.BOLT .BOULON		2			
19	90119-08M76	BOLT, WITH WASHER BOULON, AVEC RONDELLE		2			
20	97095-08016	BOLT BOULON		1			
21	92995-08600	WASHER RONDELLE		1			
22	90465-11M10	CLAMP BRIDE	2	2			MH-FOR RUS MH-FOR RUS
23	90465-08M99	CLAMP BRIDE	1	1			
24	97095-06012	BOLT BOULON	1	1			
25	92995-06600	WASHER RONDELLE	1	1			




FIG. 16 BOTTOM COWLING

CAPOT INFERIEUR

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W			REMARKS REMARQUES
1	6DR-42710-00-8D	BOTTOM COWLING ASSY ENS. EMBASE	1	1			
2	68F-85119-00	BOLT BOULON	4	4			
3	90480-21M82	GROMMET PASSE-FIL	4	4			
4	90387-06176	COLLAR COLLERETTE	4	4			
5	68T-42716-10	RUBBER, SEAL 1 JOINT EN CAOUTCHOUC 1	1	1			
6	6AU-42801-00	COWLING CLAMP COMP. BRIDE DE CAPOT COMP.	1	1			
7	97095-06012	BOLT BOULON	1	1			
8	92995-06600	WASHER RONDELLE	1	1			
9	6BL-44391-00	NIPPLE, HOSE RACCORD D'ESSENCE	1	1			
10	682-42727-00	GROMMET PASSE-FIL	1	1			
11	6DR-42761-00	STOPPER PLAQUETTE	1				
	6DR-42761-10	STOPPER PLAQUETTE		1			
12	90109-06M86	BOLT BOULON	1	1			
13	6DR-42725-00	GROMMET PASSE-FIL	1				
	6DR-42725-10	GROMMET PASSE-FIL		1			
14	68T-26367-00	PROTECTOR PROTECTEUR	1				
15	68T-42724-20	GROMMET PASSE-FIL	1				
16	90480-06M19	GROMMET PASSE-FIL	2				FOR RUS
17	6H4-42726-00	GROMMET PASSE-FIL	1				FOR RUS
	688-42726-10	GROMMET PASSE-FIL	1	1			FOR RUS
							EUR-FLUSHING KIT
							EUR-FLUSHING KIT
18	65W-42717-00	RUBBER, SEAL 2 JOINT EN CAOUTCHOUC 2	2	2			
19	68T-42741-00	APRON CAPOT LATERAL	1	1			
20	97885-06030	SCREW, PAN HEAD VIS, A ENCOCHE	2	2			
21	92995-06100	WASHER, SPRING RONDELLE, GROWER	2	2			
22	92995-06600	WASHER RONDELLE	2	2			
23	95380-06600	NUT, HEXAGON ECROU	2	2			
24	68T-42717-00	RUBBER, SEAL 2 JOINT EN CAOUTCHOUC 2	1	1			




FIG. 17 STEERING

DIRECTION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	U			REMARKS REMARQUES
1	6DR-42101-00-8D	HANDLE, STEERING POIGNEE	1				
2	90109-06M86	.BOLT .BOULON	2				
3	90109-06M80	.BOLT .BOULON	2				
4	6DR-42138-00	LEVER, THROTTLE LEVIER, ACCELERATEUR	1				
5	65W-42159-00	STAY SUPPORT	1				
6	6DR-42126-00	FRICTION, STEERING HANDLE GRIP CUVETTE, POIGNEE DE DIRECTION	1				
7	65W-42125-00	BOLT, FRICTION ADJUSTING BOULON	1				
8	91490-16010	PIN. COTTER GOUPILLE	1				
9	67D-42177-00	RUBBER, HANDLE CAOUTCHOUC, POIGNEE	1				
10	67D-42119-01	GRIP, STEERING HANDLE POIGNEE, BARRE FRANCHE	1				
11	6DR-42137-00	INDICATOR, THROTTLE INDICATEUR, ACCELERATION	1				
12	90152-05011	SCREW, COUNTERSUNK VIS, TETE NOYEE	1				
13	90201-10M02	WASHER, PLATE RONDELLE, PLATE	2				
14	90501-23215	SPRING, COMPRESSION RESSORT, COMPRESSION	1				
15	90386-08032	BUSH DOUILLE	1				
16	6DR-26301-00	THROTTLE CABLE ASSY CABLE D'ACCELERATEUR	2				
17	6DR-26316-00	BOOT, THROTTLE CABLE SOUFFLET, CABLE D'ACCELERATEUR	1				
18	66R-42171-00	BUSHING COUSSINET	1				
19	90201-43M00	WASHER, PLATE RONDELLE, PLATE	2				
20	90206-43M22	WASHER, WAVE RONDELLE, ONDULEE	2				
21	90202-43M57	WASHER, PLATE RONDELLE, PLATE	1				
22	90386-40M99	BUSH DOUILLE	1				
23	65W-42131-01	COVER, HANDLE STEERING COUVERCLE	1				
24	95780-10300	NUT, FLANGE ECROU	1				
25	95380-10700	NUT ECROU	1				
26	6DR-44111-00-8D	HANDLE, GEAR SHIFT POIGNEE, LEVIER D'EMBRAYAGE	1				
27	6DR-44173-00	LEVER, SHIFT CONTROL POIGNEE, INVERSION	1				





FIG. 17 STEERING

DIRECTION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	E			REMARKS REMARQUES
28	6DR-42129-00	BUSHING, RUBBER DOUILLE, CAOUTCHOUC	1				
29	97780-60920	SCREW, TAPPING VIS, TETE BOMBEE	2				
30	97095-08035	BOLT BOULON	1				
31	92995-08600	WASHER RONDELLE	1				
32	90386-26MA3	BUSH DOUILLE	2				
33	90206-26M25	WASHER, WAVE RONDELLE, ONDULEE	1				
34	90202-26M59	WASHER, PLATE RONDELLE, PLATE	1				
35	68T-44113-01	CAM PLATE, HANDLE CAME, VERROUILLAGE	1				
36	6DR-44116-00	SPRING RESSORT	1				
37	66R-44118-00	BRACKET SUPPORT	1				
38	66R-48538-00	CLAMP, CABLE 1 COLLIER	1				
39	63D-48538-00	CLAMP, CABLE 1 COLLIER	1				
40	6DR-48321-00	CABLE CABLE	1				
41	90447-13015	TUBE DURITE	1				
42	6DR-82594-00	CLAMP BRIDE	1				
43	90151-05003	SCREW, COUNTERSUNK VIS, TETE NOYEE	2				
44	99080-04600	CIRCLIP CIRCLIP	1				
45	6DR-44114-00	STOPPER PLAQUETTE	1				
46	66R-48344-00	CABLE END, REMOTE CONTROL CHAPE CABLE	1				
47	90201-06M62	WASHER, PLATE RONDELLE, PLATE	1				
48	90170-05M38	NUT ECROU	1				
49	91490-20012	PIN, COTTER GOUPILLE	1				
50	65W-82575-01	ENGINE STOP SWITCH ASSY COUPE CIRCUIT CPLT	1				
51	682-82556-00	.LANYARD, STOP SWITCH .CORDON DU COUPE CIRCUIT	1				
52	689-8257Y-00	.CAP .COUVERCLE	1				




6DR1100-M190

FIG. 18 STEERING FRICTION

CUVETTE POIGNEE DE DIRECTION

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	MH	E				REMARKS REMARQUES
1	6AH-42508-01	STEERING FRICTION ASSY DIRECTION FRICTION (ENS.)	1					
2	68T-42525-01	.PLATE, FRICTION .PLAQUE, FRICTION	1					
3	90119-05018	.BOLT, WITH WASHER .BOULON, AVEC RONDELLE	2					
4	67C-42562-00	.SHAFT, STEERING LOCK .ARBRE, ANTIVOL DE DIRECTION	1					
5	90202-10M56	.WASHER, PLATE .RONDELLE, PLATE	1					
6	68T-42561-00	.KNOB, STEERING LOCK .BOUTON	1					
7	689-43633-00	.COVER, TILT LEVER .COUVERCLE	1					
8	65W-42528-00	.PLATE, FRICTION .PLAQUE, FRICTION	2					
9	90387-05053	.COLLAR .COLLERETTE	1					
10	90387-05054	.COLLAR .COLLERETTE	1					
11	97095-05020	.BOLT .BOULON	1					
12	92995-05600	.WASHER .RONDELLE	1					
13	90209-10M26	.WASHER .RONDELLE	1					
14	90185-10M14	.NUT, SELF-LOCKING .ECROU, AUTO-BLOQUANT	1					
15	6AH-42527-00	.PLATE, FRICTION .PLAQUE, FRICTION	1					
16	90101-08022	.BOLT .BOULON	2					
17	90201-08065	.WASHER, PLATE .RONDELLE, PLATE	2					
18	68T-43155-00	.MARK 1 .ETIQUETTE 1	1					
19	90201-106M5	.WASHER, PLATE .RONDELLE, PLATE	1					




FIG. 19 CONTROL 1

COMMANDE 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	E			REMARKS REMARQUES
1	68T-42726-00	GROMMET PASSE-FIL	1				
2	68T-44121-03	LEVER, SHIFT ROD LEVIER, TIGE D'INVERSION	1				
3	6G1-41662-01-94	BRACKET 2 SUPPORT 2	2				
4	90109-06M81	BOLT BOULON	2				
5	90464-10M60	CLAMP BRIDE	1				
6	91690-30014	PIN, SPRING AGRAFFE	1				
7	65W-44116-00	SPRING RESSORT	1				
8	6DR-44117-00	BRACKET SUPPORT	1				
9	90109-06M86	BOLT BOULON	1				
10	68T-44143-00	ROD, SHIFT TIGE D'EMBRAYAGE	1				S(17.0") S(17.0")
	68T-44143-10	ROD, SHIFT TIGE D'EMBRAYAGE	1				L(22.0") L(22.0")
11	90468-18001	CLIP JONC	1				
12	61N-44146-00	CONNECTOR, SHIFT ROD 2 CONNECTEUR, TIGE D'INVERSION 2	1				
13	95380-06700	NUT ECROU	1				
14	68T-48538-00	CLAMP, CABLE 1 COLLIER	1				
15	97095-06012	BOLT BOULON	1				
16	92995-06600	WASHER RONDELLE	1				
17	63D-48538-00	CLAMP, CABLE 1 COLLIER	1				
18	68T-41638-00	PULLEY POULIE	1				
19	68T-41283-00	LEVER, FREE ACCEL. LEVIER	1				
20	90387-06M59	COLLAR COLLERETTE	1				
21	6AU-41211-00	LINK, ACCEL. BIELLETTE, ACCELERATION	1				
22	68T-14497-00	STAY, THROTTLE WIRE SUPPORT DE BOISSEAU	1				
23	90201-06M62	WASHER, PLATE RONDELLE, PLATE	1				
24	97595-06545	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	1				
25	97095-06012	BOLT BOULON	1				
26	92995-06600	WASHER RONDELLE	1				




FIG. 19 CONTROL 1

COMMANDE 1

[illegible]




FIG. 20 CONTROL 2

COMMANDE 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W		REMARKS REMARQUES
1	6DR-48531-00	BRACKET, REMOTE CONTROL 1 ETRIER 1, COMMANDE A DISTANCE		1		
2	682-48538-50	CLAMP, CABLE 1 COLLIER		2		
3	91690-30012	PIN, SPRING AGRAFFE		2		
4	97095-06012	BOLT BOULON		2		
5	92995-06600	WASHER RONDELLE		2		
6	6AU-44111-10	HANDLE, GEAR SHIFT POIGNEE, LEVIER D'EMBRAYAGE		1		
7	93210-12327	O-RING JOINT TORIQUE		1		
8	97095-05016	BOLT BOULON		1		
9	92995-05600	WASHER RONDELLE		1		
10	68T-44121-03	LEVER, SHIFT ROD LEVIER, TIGE D'INVERSION		1		
11	6G1-41662-01-94	BRACKET 2 SUPPORT 2		2		
12	90109-06M81	BOLT BOULON		2		
13	90464-10M60	CLAMP BRIDE		1		
14	91690-30014	PIN, SPRING AGRAFFE		1		
15	65W-44116-00	SPRING RESSORT		1		
16	6DR-44117-00	BRACKET SUPPORT		1		
17	90109-06M86	BOLT BOULON		1		
18	68T-44143-00	ROD, SHIFT TIGE D'EMBRAYAGE		1		S(17.0")
	68T-44143-10	ROD, SHIFT TIGE D'EMBRAYAGE		1		S(17.0") L(22.0")
19	90468-18001	CLIP JONC		1		L(22.0")
20	61N-44146-00	CONNECTOR, SHIFT ROD 2 CONNECTEUR, TIGE D'INVERSION 2		1		
21	95380-06700	NUT ECROU		1		
22	663-48344-00	CABLE END, REMOTE CONTROL CHAPE CABLE		1		
23	90468-18008	CLIP JONC		1		
24	68T-41638-00	PULLEY POULIE		1		
25	68T-41283-00	LEVER, FREE ACCEL. LEVIER		1		
26	90387-06M59	COLLAR COLLERETTE		1		




FIG. 20 CONTROL 2

[illegible]





FIG. 21 REMO CON ATTACHMENT

COMMANDE A DISTANCE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	E				REMARKS REMARQUES
1	6DR-48501-00	REMOTE CONT. ATTACHMENT ASSY. COMMANDE A DISTANCE (KIT)	1					AP AP
2	68T-48531-00	.BRACKET, REMOTE CONTROL 1 .ETRIER 1, COMMANDE A DISTANCE	1					
3	682-48538-50	.CLAMP, CABLE 1 .COLLIER	2					
4	91690-30012	.PIN, SPRING .AGRAFFE	2					
5	97095-06012	.BOLT .BOULON	2					
6	92995-06600	.WASHER .RONDELLE	2					
7	95380-06600	.NUT, HEXAGON .ECROU	2					
8	6AU-44111-10	.HANDLE, GEAR SHIFT .POIGNEE, LEVIER D'EMBRAYAGE	1					
9	93210-12327	.O-RING .JOINT TORIQUE	1					
10	97095-05016	.BOLT .BOULON	1					
11	92995-05600	.WASHER .RONDELLE	1					
12	663-48344-00	.CABLE END, REMOTE CONTROL .CHAPE CABLE	1					
13	90468-18008	.CLIP .JONC	1					
14	663-48344-00	.CABLE END, REMOTE CONTROL .CHAPE CABLE	1					
15	90468-18008	.CLIP .JONC	1					
16	6DR-42761-10	.STOPPER .PLAQUETTE	1					
17	6DR-42725-10	.GROMMET .PASSE-FIL	1					
18	68T-42725-10	.GROMMET .PASSE-FIL	1					
19	63V-48511-01	HOOK, STEERING ATTACHE, DIRECTION	1					AP AP
20	97575-08535	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	1					AP AP
21	90185-08057	NUT, SELF-LOCKING ECROU,AUTO-BLOQUANT	1					AP AP




6DR1700-M190

FIG. 22 BRACKET 1

SUPPORT 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W			REMARKS REMARQUES
1	6AH-43111-00-8D	BRACKET, CLAMP 1 PRESSE 1	1	1			
2	6AH-43112-00-8D	BRACKET, CLAMP 2 PRESSE 2	1	1			
3	6E0-43118-01	HANDLE, TRANSOM CLAMP POIGNEE DE VIS DE PRESSE	2	2			
4	90243-04M01	PIN GOUPILLE	2	2			
5	6E7-43116-00	SCREW, TRANSOM CLAMP VIS DE PRESSE	2	2			
6	648-43114-01	PAD, TRANSOM CLAMP RONDELLE D'APPUI	2	2			
7	69A-43131-00	BOLT, CLAMP BRACKET BOULON, PRESSE	1	1			FOR RIDE GUIDE FOR RIDE GUIDE
8	90386-22MA4	BUSH DOUILLE	2	2			
9	66R-43113-00	PLATE, CLAMP BRACKET PLAQUETTE, PRESSE	1	1			
10	90185-22043	NUT, SELF-LOCKING ECROU, AUTO-BLOQUANT	2	2			
11	90387-06M13	COLLAR COLLERETTE	1	1			
12	90101-06M18	BOLT BOULON	1	1			
13	92995-06600	WASHER RONDELLE	1	1			
14	95380-06700	NUT ECROU	1	1			
15	6L2-43160-01	TILT ROD ASSY BROCHE D'INCLINAISON (ENS.)	1	1			
16	689-43165-00	.PLATE, TILT LOCK .TAQUET, BROCHE INCLINAISON	1	1			
17	91690-30008	.PIN, SPRING .AGRAFFE	1	1			
18	90502-10M07	SPRING, CONICAL RESSORT, CONIQUE	1	1			
19	6AH-43311-00-8D	BRACKET, SWIVEL 1 SUPPORT, PIVOT 1	1	1			S(17.0") S(17.0")
	6AU-43311-10-8D	BRACKET, SWIVEL 1 SUPPORT, PIVOT 1	1	1			L(22.0") L(22.0")
20	6DR-43631-00	LEVER, TILT LEVIER, INCLINAISON	1	1			
21	6DR-43616-00	ROD, TILT LOCK TIGE	1	1			
22	68T-43646-00	SHAFT, LEVER AXE, LEIVER	1	1			
23	6DR-43641-00	LEVER, TILT LEVIER, INCLINAISON	1	1			
24	6AH-43617-00	ROD, TILT LOCK TIGE	1	1			
25	99080-05600	CIRCLIP CIRCLIP	2	2			
26	6AH-43350-00	RECEIVER ASSY RECEIVER ASSY	1	1			



 6DR1300-M230




FIG. 23 BRACKET 2

SUPPORT 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W		REMARKS REMARQUES
1	6DR-42511-00-8D	BRACKET, STEERING CADRE, DIRECTION	1			S(17.0°)
	6DR-42511-10-8D	BRACKET, STEERING CADRE, DIRECTION	1			S(17.0°)
	6AU-42511-00-8D	BRACKET, STEERING CADRE, DIRECTION		1		L(22.0°)
	6AU-42511-10-8D	BRACKET, STEERING CADRE, DIRECTION		1		S(17.0°)
2	90386-40001	BUSH DOUILLE	1	1		L(22.0°)
3	90209-40008	WASHER RONDELLE	1	1		
4	90386-30048	BUSH DOUILLE	1	1		
5	93210-29M94	O-RING JOINT TORIQUE	1	1		
6	90386-30M60	BUSH DOUILLE	1	1		
7	90116-08M54	BOLT, STUD GOUJON	2	2		
8	68T-44517-00	MOUNT RUBBER SILENT-BLOC	1	1		
9	68T-44526-00	PLATE PLAQUE	1	1		
10	95380-08600	NUT ECROU	2	2		
11	97575-06525	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	2	2		
12	6AU-44551-00-8D	HOUSING, LOWER MOUNT RUBBER 1 BOITIER, SILENT-BLOC INFERIEUR	2	2		
13	6AU-44557-00	MOUNT DAMPER, LOWER FRONT SILENT-BLOC, INFERIEUR AVANT	1	1		
14	682-44555-30	MOUNT DAMPER, LOWER SIDE SILENT-BLOC, INFERIEUR LATERAL	2	2		
15	90119-06012	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2	2		
16	90119-06198	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2	2		
17	90179-06M28	NUT ECROU	4	4		
18	93700-06M03	NIPPLE, GREASE PION	1	1		
19	68T-82127-00	WIRE, LEAD 2 FIL 2	1	1		
20	63V-48511-01	HOOK, STEERING ATTACHE, DIRECTION		1		
21	97575-08535	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE		1		
22	90185-08057	NUT, SELF-LOCKING ECROU,AUTO-BLOQUANT		1		




FIG. 24 UPPER CASING

FOURREAU

[illegible]




FIG. 25 OIL PAN

VENTILATEUR D'HUILE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	E				REMARKS REMARQUES
1	68T-41137-00-CA	GUIDE, EXHAUST COLLECTEUR D'ECHAPPEMENT	1	1				
2	65W-42717-00	RUBBER, SEAL 2 JOINT EN CAOUTCHOUC 2	1	1				
3	68T-45181-00	PLATE PLAQUETTE	1	1				
4	97095-08014	BOLT BOULON	1	1				
5	90430-08143	GASKET JOINT	1	1				
6	93101-12M70	OIL SEAL JOINT SPY	1	1				
7	68T-13421-01	STRAINER 2 FILTRE 2	1	1				
8	90467-11M08	CLIP JONC	1	1				
9	6G8-11575-00	RELIEF VALVE ASSY SOUPAPE DE RENTREE D'AIR	1	1				
10	93210-12M62	O-RING JOINT TORIQUE	1	1				
11	93606-19M23	PIN, DOWEL GOUPILLE	2	2				
12	68T-15311-01-CA	OIL PAN VENTILATEUR D'HUILE	1	1				
13	6H1-11372-00	NIPPLE, HOSE RACCORD, TUYAU	1	1				
14	90480-10M28	GROMMET PASSE-FIL	1	1				
15	90340-10M10	PLUG, STRAIGHT SCREW PLOT, FILETE DROIT	1	1				
16	90430-10M11	GASKET JOINT	1	1				
17	68T-15316-00	DAMPER 1 AMORTISSEUR 1	1	1				
18	68T-15317-00	SPACER, ENGINE MOUNT ENTRETOISE DE SUPPORT	1	1				
19	97885-05008	SCREW, PAN HEAD VIS, A ENCOCHE	1	1				
20	68T-13475-00	GASKET JOINT	1	1				
21	93604-12M07	PIN, DOWEL CLAVETTE	2	2				
22	90119-08005	BOLT, WITH WASHER BOULON, AVEC RONDELLE	6	6				
23	97575-08530	BOLT, WITH WASHER VIS HEXAGONAL AVEC RONDELLE	2	2				
24	68T-15362-00	PLUG, OIL LEVEL PLOT, NIVEAU D'HUILE	1	1				




FIG. 26 LOWER CASING & DRIVE 1

BOITIER D'HELICE TRANSMISSION1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W			REMARKS REMARQUES
1	6AU-45300-00-8D	LOWER UNIT ASSY UNITE INFERIEURE (ENS.)	1	1			S(17.0") S(17.0")
	6AU-45300-10-8D	LOWER UNIT ASSY UNITE INFERIEURE (ENS.)	1	1			L(22.0") L(22.0")
2	6AU-45311-00-8D	CASING, LOWER BOITIER D'HELICE	1	1			
3	6G1-45317-09	.BUSHING, DRIVE SHAFT .DOUILLE, ARBRE MOTEUR	1	1			
4	90387-14M49	COLLAR COLLERETTE	1	1			
5	93306-004U0	BEARING ROULEMENT	1	1			
6	68T-45251-00	ANODE ANODE	1	1			
7	95895-06016	BOLT, FLANGE BOULON	1	1			
8	92990-06300	WASHER, INTERNAL TOOTH RONDELLE, DENTURE INTERNE	1	1			
9	90340-08002	PLUG, STRAIGHT SCREW PLOT, FILETE DROIT	2	2			
10	90430-08003	GASKET JOINT	2	2			
11	6G1-45361-01-8D	CAP, LOWER CASING COUVERCLE, BOITIER D'HELICE	1	1			
12	6G1-45362-09	.BUSHING .COUSSINET	1	1			
13	93306-004U0	BEARING ROULEMENT	1	1			
14	93101-15074	OIL SEAL JOINT SPY	2	2			
15	93210-49046	O-RING JOINT TORIQUE	1	1			
16	93210-53M08	O-RING JOINT TORIQUE	1	1			
17	97095-06016	BOLT BOULON	2	2			
18	92995-06600	WASHER RONDELLE	2	2			
19	63V-44301-00	WATER PUMP HOUSING COMP. CARTER, POMPE A EAU (ENS)	1	1			
20	63V-44322-00	.INSERT, CARTRIDGE .CUVETTE	1	1			
21	68T-44366-00	DAMPER, WATER SEAL 2 JOINT, TUBE D'EAU 2	1	1			
22	68T-44352-00	IMPELLER TURBINE	1	1			
23	664-44338-00	KEY, WOODRUFF CLAVETTE, VOLANT	1	1			
24	93210-44398	O-RING JOINT TORIQUE	1	1			
25	68T-44323-00	OUTER PLATE, CARTRIDGE PLAQUE EXTERIEURE	1	1			
26	93604-12M07	PIN, DOWEL CLAVETTE	2	2			




FIG. 26 LOWER CASING & DRIVE 1

BOITIER D'HELICE TRANSMISSION1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W		REMARKS REMARQUES
27	97095-08045	BOLT BOULON	4	4		
28	63V-44328-01	PLATE PLAQUETTE	2	2		
29	68T-45331-00-CA	HOUSING, BEARING FLASQUE, ROULEMENT	1	1		
30	6G1-45316-09	BUSHING, DRIVE SHAFT DOUILLE, ARBRE MOTEUR	1	1		
31	93101-11M23	OIL SEAL JOINT SPY	2	2		
32	68T-45315-A0	PACKING, LOWER CASING JOINT, BOITIER D'HELICE	1	1		
33	93210-06ME6	O-RING JOINT TORIQUE	1	1		
34	97080-08025	BOLT BOULON	2	2		
35	68T-44150-00	SHIFT CAM ASSY CAME D'INVERSION	1	1		
36	6AU-45511-00	SHAFT, DRIVE ARBRE, MOTEUR	1	1		S(17.0") S(17.0")
	6AU-45511-10	SHAFT, DRIVE ARBRE, MOTEUR	1	1		L(22.0") L(22.0")
37	90467-09M05	CLIP JONC	1	1		
38	99001-07600	CIRCLIP CIRCLIP	1	1		
39	68T-45551-00	PINION (13T) PIGNON D'ATTAQUE (13D)	1	1		
40	6G1-45533-00	SHIM (T:1.90MM) CALE (T:1.90MM)	1	1		UR UR
	6G1-45533-10	SHIM (T:2.00MM) CALE (T:2.00MM)	1	1		UR UR UR
	6G1-45533-20	SHIM (T:2.10MM) CALE (T:2.10MM)	1	1		UR UR UR
	6G1-45533-30	SHIM (T:2.20MM) CALE (T:2.20MM)	1	1		UR UR UR
41	68T-45560-00	GEAR 1 (27T) PIGNON 1 (27T)	1	1		
42	664-45587-01	SHIM (T:0.10MM) CALE (T:0.10MM)	1	1		UR UR
	664-45587-10	SHIM (T:0.12MM) CALE (T:0.12MM)	1	1		UR UR UR
	664-45587-20	SHIM (T:0.15MM) CALE (T:0.15MM)	1	1		UR UR UR
	664-45587-30	SHIM (T:0.18MM) CALE (T:0.18MM)	1	1		UR UR UR
	664-45587-40	SHIM (T:0.30MM) CALE (T:0.30MM)	1	1		UR UR UR
	664-45587-50	SHIM (T:0.40MM) CALE (T:0.40MM)	1	1		UR UR UR
	664-45587-60	SHIM (T:0.50MM) CALE (T:0.50MM)	1	1		UR UR
43	68T-45571-00	GEAR 2 (27T) PIGNON 2 (27T)	1	1		




FIG. 27 LOWER CASING & DRIVE 2

BOITIER D'HELICE TRANSMISSION2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W		REMARKS REMARQUES
1	68T-44361-00	TUBE, WATER 1 TUBE D'EAU 1	1	1		S(17.0") S(17.0")
	68T-44361-10	TUBE, WATER 1 TUBE D'EAU 1	1	1		L(22.0") L(22.0")
2	63V-44365-10	DAMPER, WATER SEAL 1 JOINT, TUBE D'EAU 1	1	1		
3	93604-12M07	PIN, DOWEL CLAVETTE	2	2		
4	97575-08535	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	4	4		
5	6G1-45214-00	COVER, WATER INLET 1 GRILLE, ENTREE D'EAU 1	1	1		
6	6G1-45215-00	COVER, WATER INLET 2 GRILLE, ENTREE D'EAU 2	1	1		
7	90152-05M03	SCREW, COUNTERSUNK VIS, TETE NOYEE	1	1		
8	90185-05002	NUT, NYLON ECROU, AUTO-BLOQUANT	1	1		
9	63V-45375-00	DAMPER, SEAL BOURRELET, CAOUTCHOUC	1	1		
10	6G1-45987-02	SPACER 1 ENTRETOISE 1	1	1		
11	90201-10M01	WASHER, PLATE RONDELLE, PLATE	1	1		
12	90171-10M01	NUT, CASTLE ECROU, CRENELE	1	1		
13	91490-30020	PIN, COTTER GOUPILLE	1	1		
14	6G1-45941-00	PROPELLER (3X8-1/2"X8-1/2"-N) HELICE (3X8-1/2"X8-1/2"-N)	1	1		UR UR
	6G1-45943-00	PROPELLER (3X8-1/2"X7-1/2"-N) HELICE (3X8-1/2"X7-1/2"-N)	1	1		UR UR
	6G1-45947-00	PROPELLER (3X8-1/2"X6-1/2"-N) HELICE (3X8-1/2"X6-1/2"-N)	1	1		UR UR
	6G1-45952-00	PROPELLER (3X8-1/2"X8"-N) HELICE (3X8-1/2"X8"-N)	1	1		UR UR
	6G1-45954-00	PROPELLER (3X8-1/2"X9-1/4"-N) HELICE (3X8-1/2"X9-1/4"-N)	1	1		UR UR
15	6G1-W4591-01	PROPELLER (3X9"X7"-N) HELICE (3X9"X7"-N)	1	1		UR UR
	6G1-W4592-00	PROPELLER (3X9"X5"-N) HELICE (3X9"X5"-N)	1	1		UR UR
16	6G1-45616-01	.NUT, PROPELLER .CONE, HELICE	1	1		
17	90201-10M02	.WASHER, PLATE .RONDELLE, PLATE	1	1		






FIG. 29 STEERING GUIDE

FIXATION DE DIRECTION

[illegible]




6DR3300-P300

FIG. 30 REMOTE CONTROL BOX

BOITIER DE COMMANDE A DISTANCE

[illegible]




6FX1300-P350

FIG. 31 REMOTE CONTROL ASSY

BOITIER DE COMMANDE A DISTANCE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W		REMARKS REMARQUES
1	703-48201-21	REMOTE CONTROL ASSY BOITIER DE COMMANDE A DISTANCE		1		AP WITHOUT PT/T SW. AP WITHOUT PT/T SW.
2	703-48232-00	.GEAR .PIGNON		1		
3	703-48271-00	.ARM, SHIFT .BRAS		1		
4	703-48261-01	.ARM, THROTTLE .BRAS, ACCELERATION		1		
5	703-48235-00	.BUSHING .COUSSINET		1		
6	703-48152-10	.KNOB, FREE ACCEL. .BOUTON		1		
7	703-48268-00	.SPACER .ENTRETOISE		1		
8	703-48264-00	.FRICTION, THROTTLE .FRICTION, ACCELERATION		1		
9	95380-05600	.NUT .ECROU		1		
10	97380-05025	.BOLT .BOULON, HEXAGONAL		1		
11	703-48265-10	.SHAFT, FRICTION .AXE, COPILOTE		1		
12	93430-06024	.CIRCLIP .CLIPS		3		
13	703-48245-00	.PLATE, LOCK .PLAQUE, VERROU		1		
14	703-48252-00	.ROLLER, CAM .POULIE		1		
15	701-48248-00	.ROLLER, FREE ACCEL. .POULIE		1		
16	703-48198-00	.WASHER, WAVE .RONDELLE, ELASTIQUE ONDULEE		1		
17	703-48243-00	.BUSHING .COUSSINET		1		
18	703-48236-00	.BUSHING 1 .POULIE		2		
19	703-48189-00	.RETAINER .FLASQUE		1		
20	703-48234-00	.ROLLER, DETENT .POULIE		1		
21	703-48345-01	.CABLE END, REMOTE CONTROL 2 .CHAPE CABLE		2		
22	703-48358-00	.ANCHOR, CABLE .COLLIER		1		
23	703-48244-00	.SPRING, FREE ACCEL. .RESSORT		1		
24	703-48238-00	.SPRING, DETENT .RESSORT		5		
25	703-48211-10	.HOUSING, 1 .CORPS		1		
26	703-48212-10	.BACK PLATE 1 .PLAQUETTE 1		1		
27	703-48213-10	.BACK PLATE 2 .PLAQUETTE 2		1		



6FX1300-P350

FIG. 31 REMOTE CONTROL ASSY

BOITIER DE COMMANDE A DISTANCE

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W			REMARKS REMARQUES
28	703-48221-10	.LEVER, CONTROL .LEVIER, COMMANDE		1			SINGLE SINGLE
29	703-48246-00	.SPACER .ENTRETOISE		1			
30	703-48227-00	.SPRING, NEUTRAL LOCK .RESSORT		1			
31	703-48222-30	.GRIP, CONTROL LEVER .POIGNEE, COMMANDE LEVIER		1			
32	703-48223-10	.LOCK, NEUTRAL .VERROU, NEUTRAL		1			
33	703-48225-10	.COVER .COUVERCLE		1			
34	703-48219-10	.COVER, LEAD .COUVERCLE		1			
35	703-48281-00	.SCREW .VIS		2			
36	703-44189-20	.SCREW .VIS		7			
37	97380-08030	.BOLT .BOULON, HEXAGONAL		1			
38	92990-08600	.WASHER, PLATE .RONDELLE, PLATE		1			
39	703-48128-10	.SCREW 2 .VIS 2		3			
40	98580-04006	.SCREW, PAN HEAD .VIS		2			
41	703-48129-00	.SCREW 3 .VIS 3		2			
42	703-44189-30	.SCREW .VIS		3			
43	95380-06600	.NUT, HEXAGON .ECROU		3			SINGLE SINGLE
44	703-48293-10	.SPACER, REMOTE CONTROL .ENTRETOISE		1			
45	701-48287-00	.WASHER .RONDELLE		3			
46	703-48215-10	.GRAPHIC .ADHESIF		1			
47	6X3-44191-00	.INDICATOR, SHIFT .ETIQUETTE, EMBRAYAGE		1			
48	703-82510-44	.MAIN SWITCH ASSY .CONTACTEUR A CLEF COMPLET		1			
49	703-82577-00	.CAP, KEY .CABOCHON		1			
50	6K1-82532-00	.CAP .COUVERCLE		1			
51	703-82531-00	.WIRE, LEAD (L70) .FIL (L70)		1			
52	688-82575-02	.ENGINE STOP SWITCH ASSY .COUPE CIRCUIT CPLT		1			
53	682-82556-00	.LANYARD, STOP SWITCH .CORDON DU COUPE CIRCUIT		1			
54	688-8258A-20	.EXTENSION, WIRE HARNESS (4.9M) .EXTENSION, FAISCEAU DE FILS (4		1			
							(10P) (10P)




FIG. 32 OPTIONAL PARTS 1

PIECES OPTIONNELLES 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	E		REMARKS REMARQUES
1	6DR-W8180-00	ELECTRIC STARTER KIT KIT DEMARREUR ELECTRIQUE	1			AP AP
2	68T-81800-00	STARTING MOTOR ASSY DEMARREUR ELECTRIQUE COMPLET	1			
3	68T-81857-00	.PINION STOPPER SET .BUTEE PIGNON	1			
4	689-81807-12	.GEAR ASSY, STARTING MOTOR .PIGNON, DEMARREUR ELECTRIQUE	1			
5	6F5-81830-10	.FRONT BRACKET ASSY .SUPPORT AVANT	1			
6	689-81831-00	.METAL, FRONT .METAL, AVANT	1			
7	689-81847-11	.O-RING .JOINT TORIQUE	2			
8	689-81809-11	.WASHER KIT .JEU DE RONDELLES	1			
9	689-81850-11	.ARMATURE ASSY .INDUIT	1			
10	689-81810-11	.STATOR ASSY .STATOR COMPLET	1			
11	689-81840-11	.BRUSH HOLDER ASSY .SUPPORT DE CHARBON	1			
12	689-81811-11	.BRUSH 1 .CHARBON 1	1			
13	689-81812-11	.BRUSH 2 .CHARBON 2	1			
14	689-81813-10	.SPRING, BRUSH .RESSORT, DE CHARBON	2			
15	689-81820-11	.REAR BRACKET ASSY .SUPPORT ARRIERE COMPLET	1			
16	689-81826-10	.BOLT .BOULON	2			
17	90119-08M76	BOLT, WITH WASHER BOULON, AVEC RONDELLE	2			
18	97095-08016	BOLT BOULON	1			
19	92995-08600	WASHER RONDELLE	1			
20	6G8-82117-00	WIRE, LEAD FIL	1			
21	90446-10M86	HOSE (L140) DURITE (L140)	1			
22	68T-81940-00	STARTER RELAY ASSY LANCEUR RELAIS (ENS.)	1			
23	97595-06610	BOLT, WITH WASHER VIS HEXAGONAL AVC RONDELLE	2			
24	68T-81945-01	PLATE, SWITCH FITTING PLAQUE, FIXATION DU RELAIS	1			
25	97095-06012	BOLT BOULON	1			
26	92995-06600	WASHER RONDELLE	1			
27	90465-12M56	CLAMP BRIDE	1			




FIG. 32 OPTIONAL PARTS 1

PIECES OPTIONNELLES 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	E			REMARKS REMARQUES
28	6F5-82540-01	NEUTRAL SWITCH ASSY CONTACTEUR DE POINT-MORT	1				
29	68T-81870-00	STARTING SWITCH ASSY CONTACT A CLEF	1				
30	68T-81821-00	COVER, SWITCH COUVERCLE, COMMUTATEUR	1				
31	90465-11M10	CLAMP BRIDE	1				
32	68T-82150-00	FUSE HOLDER ASSY SUPPORT DE FUSIBLE	1				
33	66V-82151-00	.FUSE (10A-BL) .FUSIBLE (10A-BL)	2				
34	68T-82171-01	STAY, FUSE BOX SUPPORT, BOITE A FUSIBLES	1				
35	67F-2812A-00	PULLER, FUSE TENDEUR, FUSIBLE	1				
36	68T-82105-01	BATTERY CABLE (L: 2.1M) CABLE DE BATTERIE (L: 2.1M)	1				
37	68T-82594-00	CLAMP BRIDE	1				
38	90151-05003	SCREW, COUNTERSUNK VIS, TETE NOYEE	2				




FIG. 33 OPTIONAL PARTS 2

[illegible]




FIG. 35 REPAIR KIT 1

KITS DE REPARATION 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	MH	E				REMARKS REMARQUES
1	6AU-W0001-00	POWER HEAD GASKET KIT POCHETTE DE JINTS TETE MOTRICE	1	1				
2	93102-18M21	.OIL SEAL .JOINT SPY	1	1				
3	68T-11181-00	.GASKET, CYLINDER HEAD 1 .JOINT, DE CULASSE 1	1	1				
4	68T-11356-00	.SEAL, CYLINDER 2 .JOINT, SPY CYLINDRE	1	1				
5	68T-11169-A0	.GASKET, BREATHER COVER .JOINT, COUVERCLE DE RENIFLARD	1	1				
6	93210-13M63	.O-RING .JOINT TORIQUE	1	1				
7	93102-30M22	.OIL SEAL .JOINT SPY	1	1				
8	93101-25M69	.OIL SEAL .JOINT SPY	1	1				
9	68T-11351-00	.GASKET, CYLINDER .JOINT, D'EMBASE	1	1				
10	6G8-12414-A0	.GASKET, COVER .JOINT, COUVERCLE	1	1				
11	68T-41114-A0	.GASKET, EXHAUST OUTER COVER .JOINT, COUVERCLE D'ECHAPPEMENT	1	1				
12	90280-03M01	.KEY, WOODRUFF .CLAVETTE, DEMI-LUNE	1	1				
13	68T-13645-00	.GASKET, MANIFOLD 1 .JOINT, TUBULURE 1	1	1				
14	68T-13646-A0	.GASKET, MANIFOLD 2 .JOINT, TUBULURE 2	2	2				
15	93210-31MJ5	.O-RING .JOINT TORIQUE	1	1				
16	68T-13329-00	.GASKET, PUMP COVER .JOINT, COUVERCLE DE POMPE	1	1				
17	93210-24M79	.O-RING .JOINT TORIQUE	1	1				
18	93210-20M65	.O-RING .JOINT TORIQUE	1	1				




FIG. 36 REPAIR KIT 2

KITS DE REPARATION 2

[illegible]




FIG. 37 REPAIR KIT 3

KITS DE REPARATION 3

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	M/H	W				REMARKS REMARQUES
1	68T-W0001-20	LOWER UNIT GASKET KIT POCHETTE DE JOINTS EMBASE	1	1				
2	93101-12M70	.OIL SEAL .JOINT SPY	1	1				
3	90430-10M11	.GASKET .JOINT	1	1				
4	68T-13475-00	.GASKET .JOINT	1	1				
5	90430-08003	.GASKET .JOINT	2	2				
6	93101-15074	.OIL SEAL .JOINT SPY	2	2				
7	93210-49046	.O-RING .JOINT TORIQUE	1	1				
8	93210-53M08	.O-RING .JOINT TORIQUE	1	1				
9	93210-44398	.O-RING .JOINT TORIQUE	1	1				
10	93101-11M23	.OIL SEAL .JOINT SPY	2	2				
11	68T-45315-A0	.PACKING, LOWER CASING .JOINT, BOITIER D'HELICE	1	1				
12	93210-06ME6	.O-RING .JOINT TORIQUE	1	1				
13	68T-W0078-00	WATER PUMP REPAIR KIT KIT DE REPARATION DE LA POMPE	1	1				
14	63V-44322-00	.INSERT, CARTRIDGE .CUVETTE	1	1				
15	68T-44366-00	.DAMPER, WATER SEAL 2 .JOINT, TUBE D'EAU 2	1	1				
16	68T-44352-00	.IMPELLER .TURBINE	1	1				
17	664-44338-00	.KEY, WOODRUFF .CLAVETTE, VOLANT	1	1				
18	93210-44398	.O-RING .JOINT TORIQUE	1	1				
19	68T-44323-00	.OUTER PLATE, CARTRIDGE .PLAQUE EXTERIEURE	1	1				
20	97095-08045	.BOLT .BOULON	4	4				

NUMERICAL INDEX
INDEX NUMERIQUE

PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.
6G1-W4591-01	27 - 15	90170-24M09	9 - 10	90387-05054	18 - 10	90465-12M56	14 - 11	92995-06100	16 - 21	93210-16275	29 - 9
6G1-W4592-00	27 - 15	90171-10M01	27 - 12	90387-06138	22 - 34		32 - 27	92995-06600	5 - 13	93210-20M65	10 - 25
6DR-W8180-00	32 - 1	90179-06M28	23 - 17	90387-06138	16 - 4	90467-08M18	7 - 22		10 - 4		35 - 18
90101-06M18	22 - 12	90185-05002	27 - 8	90387-06M13	22 - 11	90467-09M05	26 - 37		11 - 23	93210-24M79	5 - 23
90101-08022	18 - 16	90185-08057	21 - 21	90387-06M59	19 - 20	90467-09M09	10 - 7		12 - 15		35 - 17
90105-06188	7 - 13		23 - 22		20 - 26		10 - 10		13 - 5	93210-29M94	23 - 5
90105-06M14	9 - 3	90185-09M01	29 - 3	90387-06M70	7 - 12		10 - 27		13 - 7	93210-31MJ5	7 - 11
90105-08M36	5 - 6	90185-10M14	18 - 14	90387-10M42	29 - 5	90467-10M04	3 - 17		13 - 14		35 - 15
90105-08M78	5 - 7	90185-22043	22 - 10	90387-13M56	6 - 9	90467-11M08	25 - 8		14 - 10	93210-44398	26 - 24
90109-06M80	17 - 3	90201-06M62	17 - 47	90387-14M03	6 - 10	90468-18001	19 - 11		14 - 15		37 - 9
90109-06M81	19 - 4		19 - 23	90387-14M49	26 - 4		20 - 19		15 - 25		37 - 18
	20 - 12		20 - 29	90430-08003	1 - 8	90468-18008	20 - 23		16 - 8	93210-49046	26 - 15
90109-06M84	22 - 39	90201-06M94	9 - 5		26 - 10		20 - 36		16 - 22		37 - 7
90109-06M86	16 - 12	90201-08065	18 - 17		37 - 5		21 - 13		16 - 39	93210-53M08	26 - 16
	17 - 2	90201-106M5	18 - 19	90430-08143	25 - 5		21 - 15		16 - 53		37 - 8
	19 - 9	90201-10M01	27 - 11	90430-10M11	1 - 6	90480-06M19	16 - 16		19 - 16	93306-004U0	26 - 5
	19 - 30	90201-10M02	17 - 13		25 - 16		16 - 28		19 - 26		26 - 13
	20 - 17		27 - 17		37 - 3	90480-10627	9 - 13		20 - 5	93430-04M03	22 - 35
	20 - 38	90201-10M20	29 - 2	90445-09074	7 - 7	90480-10M28	25 - 14		20 - 32	93430-06024	31 - 12
90116-08M54	23 - 7	90201-10M63	29 - 7	90445-09M20	7 - 7	90480-13018	14 - 13		21 - 6	93450-15023	4 - 8
90119-05018	18 - 3	90201-12472	12 - 12		7 - 26	90480-14M54	24 - 4		22 - 13	93604-12M07	24 - 8
90119-06012	23 - 15	90201-13201	9 - 4	90445-10046	10 - 5	90480-21M82	16 - 3		26 - 18		25 - 21
90119-06014	12 - 6	90201-15M89	26 - 44	90445-10M50	10 - 9	90480-25003	13 - 9		32 - 26		26 - 26
90119-06049	5 - 8	90201-43M00	17 - 19	90445-16010	10 - 11	90501-12M40	6 - 11		33 - 6		27 - 3
90119-06198	23 - 16	90202-10M56	18 - 5	90446-10M86	14 - 5	90501-140A1	26 - 49		34 - 3	93606-19M23	25 - 11
90119-06MA1	12 - 8	90202-26M59	17 - 34		32 - 21	90501-23215	17 - 14	92995-08600	15 - 21	93700-06M03	23 - 18
90119-06MA2	3 - 10	90202-43M57	17 - 21	90447-13014	10 - 28	90502-10M07	22 - 18		17 - 31	94702-00274	1 - 4
90119-06MA3	3 - 15	90206-10M24	22 - 40	90447-13015	17 - 41	90506-18014	22 - 27		32 - 19		5 - 24
	7 - 5	90206-26M25	17 - 33	90447-13M00	16 - 31	90506-20020	22 - 31	93101-11M23	26 - 31	95380-04600	10 - 23
	13 - 10	90206-43M22	17 - 20		16 - 45	90506-20025	22 - 27		37 - 10	95380-05600	31 - 9
90119-06MA5	7 - 4	90209-10M26	18 - 13	90464-10M53	10 - 29	90506-23016	22 - 31	93101-12M70	25 - 6	95380-06600	16 - 23
90119-08005	25 - 22	90209-40008	23 - 3	90464-10M60	19 - 5	91490-16010	17 - 8		37 - 2		21 - 7
90119-08020	15 - 3	90243-04M01	22 - 4		20 - 13	91490-20012	17 - 49	93101-15074	26 - 14		31 - 43
90119-08046	15 - 2	90266-04005	2 - 6	90465-08M83	7 - 16	91490-30020	27 - 13		37 - 6	95380-06700	19 - 13
90119-08M29	3 - 4	90280-03M01	9 - 11		7 - 27	91690-30008	22 - 17	93101-25M69	4 - 10		20 - 21
90119-08M76	15 - 19		35 - 12	90465-08M99	7 - 15	91690-30010	14 - 18		35 - 8		22 - 14
	32 - 17	90280-04M06	12 - 10		15 - 23	91690-30012	20 - 3	93102-18M21	9 - 17	95380-08600	23 - 10
90151-05003	17 - 43	90338-06M20	16 - 26	90465-11M10	3 - 12		21 - 4		35 - 2	95380-10700	17 - 25
	32 - 38	90340-08002	26 - 9		3 - 18	91690-30014	19 - 6	93102-30M22	4 - 9	95780-10300	17 - 24
90152-05011	17 - 12	90340-10M10	25 - 15		7 - 23		20 - 14		35 - 7	95895-06016	26 - 7
90152-05M03	27 - 7	90386-08032	17 - 15		10 - 6	91690-50014	7 - 6	93210-03261	14 - 22	97080-08025	26 - 34
90157-05M16	28 - 6	90386-22MA4	22 - 8		12 - 9	92907-04600	5 - 17	93210-06ME6	26 - 33	97095-05010	12 - 7
90167-05017	2 - 4	90386-26MA3	17 - 32		13 - 17	92990-04600	14 - 20		37 - 12	97095-05016	20 - 8
90167-06002	16 - 36	90386-30048	23 - 4		15 - 22	92990-06300	26 - 8	93210-12327	20 - 7		21 - 10
	16 - 50	90386-30M60	23 - 6		16 - 30	92990-08600	31 - 38		21 - 9	97095-05020	18 - 11
90170-05M38	17 - 48	90386-40001	23 - 2		16 - 44	92995-05600	18 - 12	93210-12M62	25 - 10	97095-06008	24 - 6
90170-09M03	29 - 4	90386-40M99	17 - 22		32 - 31		20 - 9	93210-13M63	5 - 21	97095-06012	13 - 6
90170-12066	12 - 11	90387-05053	18 - 9		34 - 4		21 - 11		35 - 6		13 - 13

NUMERICAL INDEX
INDEX NUMERIQUE

PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.
97095-06012	14 - 9	97885-05008	25 - 19								
	14 - 14	97885-06030	16 - 20								
	15 - 24	98507-04010	5 - 16								
	16 - 7	98580-04006	31 - 40								
	16 - 38	98980-05025	5 - 19								
	16 - 52	99001-07600	26 - 38								
	19 - 15	99080-04600	17 - 44								
	19 - 25	99080-05600	22 - 25								
	20 - 4		22 - 29								
	20 - 31		22 - 37								
	21 - 5	99530-10114	5 - 5								
	32 - 25	99530-12016	3 - 3								
	33 - 5										
	34 - 2										
97095-06016	26 - 17										
97095-06020	5 - 12										
	11 - 22										
	12 - 14										
	13 - 4										
97095-06025	10 - 3										
97095-08014	25 - 4										
97095-08016	15 - 20										
	32 - 18										
97095-08035	17 - 30										
97095-08045	26 - 27										
	37 - 20										
97380-05025	31 - 10										
97380-08030	31 - 37										
97575-06514	24 - 3										
97575-06525	23 - 11										
97575-08530	25 - 23										
97575-08535	21 - 20										
	23 - 21										
	24 - 9										
	27 - 4										
97595-05514	2 - 11										
97595-06510	7 - 17										
	7 - 28										
97595-06530	9 - 16										
97595-06545	19 - 24										
	20 - 30										
97595-06610	14 - 7										
	32 - 23										
97595-06630	10 - 24										
97780-40512	13 - 3										
97780-60920	17 - 29										
97880-04008	14 - 19										
97885-05008	24 - 7										