



**PARTS
CATALOGUE
CATALOGUE
DE PIÉCES DÉTACHÉES**

H3.7AV(HARMO)-2021 (6JM1)



1V6JM-300FA

()

H3.7AV
PARTS CATALOGUE
©2021 by Yamaha Motor Co., Ltd.
1st edition, September 2021
All rights reserved.
Any reprinting or unauthorized use
without the written permission of
Yamaha Motor Co., Ltd.
is expressly prohibited.
Printed in Japan.

H3.7AV
CATALOGUE DE PIECES DETACHEES
©2021 par Yamaha Motor Co., Ltd.
1^{re} édition, septembre 2021
Tous droits réservés
Toute réimpression ou utilisation
non autorisée sans la permission écrite
de la Yamaha Motor Co., Ltd.
est formellement interdite.
Imprimé au Japon

FOREWORD

This Parts Catalogue is related to the parts for the model(s) on the cover page. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

1. Modifications or additions which have been made after the issue of the Parts Catalogue will be announced in the Parts News.
It is advisable that you make the necessary corrections to the Parts Catalogue according to the Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

“UR” Use specified parts number.

“UN” Use as many as needed.

“AP” Alternate Parts

“LM” Locally Made (Parts need to be ordered locally)

“F#” Frame No. (Applicable machine No.)

“O/S” Over Size

3. The number of components for assembly

- Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.
- The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	

4. Applicable colours of graphics are represented in the “REMARKS” as shown below.


PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	FOR MXR

5. Note that the illustrations for reference in finding parts numbers are not to be used for assembling. When assembling, please use the applicable service manual.

6. The asterisk (*) before a reference number indicates modified items after the first edition.

7. Applicable Serial No.

Engine Serial No.



8. Applicable Engine Starting Serial No.

Model	Serial No.	Model	Serial No.
H3.7AV	6JM-1000001		

9. Applicable Colour Code

Abbreviation	Colour Name	Colour Code
S3	SILVER 3	0791

10. Quantity Column Information

Column No.	Name Of Q'ty Column	Applicable Model
1	6JM1	H3.7AV(HARMO)

AVANT-PROPOS

Ce catalogue de pièces détachées concerne les pièces pour le(s) modèle(s) indiqué(s) sur la page de couverture. Lorsque vous commandez des pièces de rechange, veuillez vous référer à ce catalogue de pièces détachées et indiquer clairement les numéros et les noms des pièces détachées.

1. Les modifications ou ajouts ayant été effectués après la parution du catalogue de pièces détachées seront décrits dans les Bulletins d'information concernant les pièces détachées.

Il est recommandé que vous apportiez les corrections nécessaires au catalogue des pièces détachées en vous référant aux Bulletins d'information.

2. Abréviations

Dans ce catalogue, les abréviations suivantes sont utilisées:

“UR” Utiliser le numéro de pièces spécifié.

“UN” Utiliser autant que nécessaire.

“AP” Pièces de substitution

“LM” Fabrication locale (les pièces doivent être commandées localement.)

“F#” N° de cadre (applicable au N° de série)

“O/S” Surdimensionné

3. Nombre de pièces d'un assemblage

- Les pièces fournies comme composants d'un assemblage sont précédées d'un point (.) de la manière indiquée ci-dessous.
- Le chiffre apparaissant à la droite de chaque composant indique la quantité de pièces pour chaque unité d'assemblage.

N° PIECES	DESCRIPTION	QTE	REMARQUES
2F5-83310-60	ENS. CLIGNOTANT AVANT	2	
115-83311-60	.AMPOULE (6V-18W)	1	

4. Les couleurs concernant les graphiques sont indiquées dans la colonne “REMARQUES”, comme indiqué ci-dessous.


N° PIECES	DESCRIPTION	QTE	REMARQUES
2N4-24110-00-X5	RESERVOIR A ESSENCE.	2	MXR
3J1-24240-10	.GRAPHIQUE	1	POUR MXR

5. Veuillez noter que les illustrations sont indiquées à titre de référence pour trouver les numéros de pièces, non pour être utilisées lors de l'assemblage. Lors de l'assemblage, veuillez utiliser le manuel d'entretien adéquat.

6. L'astérisque (*) placé devant un numéro de référence indique des éléments qui ont été modifiés après la première édition.

7. N° de série applicable

N° de Série du moteur



8. N° de série initial du moteur applicable

Modèle	N° de série	Modèle	N° de série
H3.7AV	6JM-1000001		

9. Code couleur applicable

Abréviation	Nom de la couleur	Code couleur
S3	SILVER 3	0791

10. Informations relatives à la colonne Quantité

N° de la colonne	Nom de la colonne Qté	Modèle applicable
1	6JM1	H3.7AV(HARMO)

CONTENTS

TOP COWLING..... 1

DRIVE UNIT..... 2

ELECTRICAL 1.....3

ELECTRICAL 2.....5

CL5 DISPLAY.....7

OPTIONAL PARTS 1.....8

OPTIONAL PARTS 2.....9

INDEX

NUMERICAL INDEX.....10

TABLE DES MATIERES

CAPOT SUPERIEUR.....	1
UNITE DE PROMENADE.....	2
PARTIE ELECTRIQUE 1.....	3
PARTIE ELECTRIQUE 2.....	5
CL5 AFFICHAGE.....	7
PIECES OPTIONNELLES 1.....	8
PIECES OPTIONNELLES 2.....	9

INDEX

INDEX NUMERIQUE.....	10
----------------------	----




FIG. 1 TOP COWLING

CAPOT SUPERIEUR

[illegible]



6JM1100-X020

FIG. 2 DRIVE UNIT

UNITE DE PROMENADE

[illegible]

SINGLE MOTER




FIG. 3 ELECTRICAL 1

PARTIE ELECTRIQUE 1

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6JM1				REMARKS REMARQUES
1	6JM-48205-01	REMOTE CONTROL ASSY BOITIER DE COMMANDE A DISTANCE	1				
2	6JM-615A0-00	HELM ASSY. ASSEMBLAGE DE GOUVERNAIL	1				
3	6JM-82386-00	EXTENSION, WIRE HARNESS EXTENSION, FAISCEAU	1				
4	6JM-482A0-01	JOYSTICK ASSY CONTROLEUR DE MANCHE A BALAI	1				
5	6Y8-83553-02	8FT POWER WIRE FIL	1				
6	6G1-82151-01	.FUSE (10A) .FUSIBLE (10A)	1				
7	6YM-83553-00	CONVERSION HARNESS FIL	2				
8	6Y8-81920-01	MULTI HUB ASSY BORNE	1				
9	6Y8-85371-01	.END OF LINE RESISTOR .RESISTANCE DE FIN DE LIGNE	1				
10	6Y9-83553-00	WIRE, LEAD FIL	1				
11	6Y8-82553-01	1FT MAIN BUS EXTENSION, FAISCEAU	1				
12	6Y8-82521-31	6FT PIGTAIL BUS FAISCEAU (L: 6FT.)	1				
13	6Y8-82582-11	CAP 1 (4PIN) COUVERCLE 1 (4P)	1				
14	6X9-8591T-12	BOAT CONTROL UNIT (SINGLE) UNITE DE COMMANDE DE BATEAU	1				ASK TO MARINE DIV
15	6X9-88107-00	GPS UNIT BLOC DE GPS	1				ASK TO MARINE DIV
16	6X9-8252H-00	.PLATE, HOLDER .PLAQUE, SUPPORT	1				
17	6X9-8255H-00	.HOLDER, SOCKET .SUPPORT	1				
18	6Y8-81920-11	IN-LINE HUB ASSY BORNE	1				
19	6X6-8258A-91	EXTENSION, WIRE HARNESS (1.5M) EXTENSION, FIL FAISCEAU (1.5M)	1				UR 1.5M-5FT MAIN-HARNESS (16P)
	6X6-8258A-51	EXTENSION, WIRE HARNESS (3.7M) EXTENSION, FIL FAISCEAU (3.7M)	1				UR 1.5M-5FT MAIN-HARNESS (16P) UR 3.7M-12FT MAIN-HARNESS (16P) UR 3.7M-12FT MAIN-HARNESS (16P)
	6X6-8258A-61	EXTENSION, WIRE HARNESS (5.2M) EXTENSION, FIL FAISCEAU (5.2M)	1				UR 5.2M-17FT MAIN-HARNESS (16P) UR 5.2M-17FT MAIN-HARNESS (16P)
	6X6-8258A-01	EXTENSION, WIRE HARNESS (6.1M) EXTENSION, FIL FAISCEAU (6.1M)	1				UR 6M-19FT MAIN-HARNESS (16P) UR 6M-19FT MAIN-HARNESS (16P)
	6X6-8258A-11	EXTENSION, WIRE HARNESS (7M) EXTENSION, FIL FAISCEAU (7M)	1				UR 7M-23FT MAIN-HARNESS (16P) UR 7M-23FT MAIN-HARNESS (16P)
	6X6-8258A-21	EXTENSION, WIRE HARNESS (8M) EXTENSION, FIL FAISCEAU (8M)	1				UR 8M-26FT MAIN-HARNESS (16P) UR 8M-26FT MAIN-HARNESS (16P)
	6X6-8258A-31	EXTENSION, WIRE HARNESS (10M) EXTENSION, FIL FAISCEAU (10M)	1				UR 10M-32FT MAIN-HARNESS (16P) UR 10M-32FT MAIN-HARNESS (16P)
	6X6-8258A-41	EXTENSION, WIRE HARNESS (12M) EXTENSION, FIL FAISCEAU (12M)	1				UR 12M-39FT MAIN-HARNESS (16P) UR 12M-39FT MAIN-HARNESS (16P)
	6X6-8258A-71	EXTENSION, WIRE HARNESS (15M) EXTENSION, FIL FAISCEAU (15M)	1				UR 15M-49FT MAIN-HARNESS (16P) UR 15M-49FT MAIN-HARNESS (16P)

This exploded view diagram illustrates the assembly of a network switch. The components are numbered as follows:

- 1:** Main switch housing.
- 2:** Fan unit.
- 3:** Internal circuit board.
- 4:** Fan speed control knob.
- 5:** RJ45 port module.
- 6:** SFP (Small Form-factor Pluggable) module.
- 7:** Ethernet cable with RJ45 connector.
- 8:** Port module assembly.
- 9:** Individual port module.
- 10:** SFP module with cable.
- 11, 21:** SFP module with cable (variant 1).
- 12, 22:** SFP module with cable (variant 2).
- 13:** Port module.
- 14:** Port module.
- 15:** Fan speed control knob cap.
- 16:** Fan speed control knob ring.
- 17:** Fan speed control knob base.
- 18:** Port module.
- 19:** Ethernet cable with SFP connector.
- 20:** Ethernet cable with RJ45 connector.

FIG. 3 ELECTRICAL 1

PARTIE ELECTRIQUE 1

[illegible]

TWIN MOTER





FIG. 4 ELECTRICAL 2

PARTIE ELECTRIQUE 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6JM1				REMARKS REMARQUES
1	6JM-48207-01	REMOTE CONTROL ASSY BOITIER DE COMMANDE A DISTANCE	1				
2	6JM-615A0-00	HELM ASSY. ASSEMBLAGE DE GOUVERNAIL	1				
3	6JM-82386-00	EXTENSION, WIRE HARNESS EXTENSION, FAISCEAU	1				
4	6JM-482A0-01	JOYSTICK ASSY CONTROLEUR DE MANCHE A BALAI	1				
5	6Y8-83553-02	8FT POWER WIRE FIL	1				
6	6G1-82151-01	.FUSE (10A) .FUSIBLE (10A)	1				
7	6YM-83553-00	CONVERSION HARNESS FIL	2				
8	6Y8-81920-01	MULTI HUB ASSY BORNE	1				
9	6Y8-85371-01	.END OF LINE RESISTOR .RESISTANCE DE FIN DE LIGNE	1				
10	6Y9-83553-00	WIRE, LEAD FIL	1				
11	6Y8-82553-01	1FT MAIN BUS EXTENSION, FAISCEAU	1				
12	6Y8-82521-31	6FT PIGTAIL BUS FAISCEAU (L: 6FT.)	1				
13	6Y8-82582-11	CAP 1 (4PIN) COUVERCLE 1 (4P)	1				
14	6X9-8591T-22	BOAT CONTROL UNIT (TWIN) UNITE DE COMMANDE DE BATEAU	1				ASK TO MARINE DIV
15	6X9-88107-00	GPS UNIT BLOC DE GPS	1				ASK TO MARINE DIV
16	6X9-8252H-00	.PLATE, HOLDER .PLAQUE, SUPPORT	1				
17	6X9-8255H-00	.HOLDER, SOCKET .SUPPORT	1				
18	6Y8-81920-11	IN-LINE HUB ASSY BORNE	1				
19	6X6-8258A-91	EXTENSION, WIRE HARNESS (1.5M) EXTENSION, FIL FAISCEAU (1.5M)	2				UR 1.5M-5FT MAIN-HARNESS (16P)
	6X6-8258A-51	EXTENSION, WIRE HARNESS (3.7M) EXTENSION, FIL FAISCEAU (3.7M)	2				UR 1.5M-5FT MAIN-HARNESS (16P) UR 3.7M-12FT MAIN-HARNESS (16P) UR 3.7M-12FT MAIN-HARNESS (16P)
	6X6-8258A-61	EXTENSION, WIRE HARNESS (5.2M) EXTENSION, FIL FAISCEAU (5.2M)	2				UR 5.2M-17FT MAIN-HARNESS (16P) UR 5.2M-17FT MAIN-HARNESS (16P)
	6X6-8258A-01	EXTENSION, WIRE HARNESS (6.1M) EXTENSION, FIL FAISCEAU (6.1M)	2				UR 6M-19FT MAIN-HARNESS (16P) UR 6M-19FT MAIN-HARNESS (16P)
	6X6-8258A-11	EXTENSION, WIRE HARNESS (7M) EXTENSION, FIL FAISCEAU (7M)	2				UR 7M-23FT MAIN-HARNESS (16P) UR 7M-23FT MAIN-HARNESS (16P)
	6X6-8258A-21	EXTENSION, WIRE HARNESS (8M) EXTENSION, FIL FAISCEAU (8M)	2				UR 8M-26FT MAIN-HARNESS (16P) UR 8M-26FT MAIN-HARNESS (16P)
	6X6-8258A-31	EXTENSION, WIRE HARNESS (10M) EXTENSION, FIL FAISCEAU (10M)	2				UR 10M-32FT MAIN-HARNESS (16P) UR 10M-32FT MAIN-HARNESS (16P)
	6X6-8258A-41	EXTENSION, WIRE HARNESS (12M) EXTENSION, FIL FAISCEAU (12M)	2				UR 12M-39FT MAIN-HARNESS (16P) UR 12M-39FT MAIN-HARNESS (16P)
	6X6-8258A-71	EXTENSION, WIRE HARNESS (15M) EXTENSION, FIL FAISCEAU (15M)	2				UR 15M-49FT MAIN-HARNESS (16P) UR 15M-49FT MAIN-HARNESS (16P)

TWIN MOTER



6JM1100-X040

FIG. 4 ELECTRICAL 2

PARTIE ELECTRIQUE 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION DESCRIPTION	6JM1				REMARKS REMARQUES
19	6X6-8258A-81	EXTENSION, WIRE HARNESS (24M) EXTENSION, FIL FAISCEAU (24M)	2				UR 24M-79FT MAIN-HARNESS (16P) UR 24M-79FT MAIN-HARNESS (16P)
20	6GR-8258A-10	HELM HARNESS 0.9M-3FT EXTENSION, FAISCEAU DE FILS	2				UR MULTIPLE ENGINES (MAIN ST) UR MULTIPLE ENGINES (MAIN ST)
	6GR-8258A-50	HELM HARNESS 1.8M-6FT EXTENSION, FAISCEAU DE FILS	2				UR MULTIPLE ENGINES (MAIN ST) UR MULTIPLE ENGINES (MAIN ST)
	6GR-8258A-60	HELM HARNESS 2.7M-9FT EXTENSION, FAISCEAU DE FILS	2				UR MULTIPLE ENGINES (MAIN ST) UR MULTIPLE ENGINES (MAIN ST)
21	6Y8-82521-01	1FT PIGTAIL BUS FAISCEAU (L: 1FT.)	1				UR UR
	6Y8-82521-11	2FT PIGTAIL BUS FAISCEAU (L: 2FT.)	1				UR UR
	6Y8-82521-21	3FT PIGTAIL BUS FAISCEAU (L: 3FT.)	1				UR UR
	6Y8-82521-31	6FT PIGTAIL BUS FAISCEAU (L: 6FT.)	1				UR UR
	6Y8-82521-41	9FT PIGTAIL BUS FAISCEAU (L: 9FT.)	1				UR UR
	6Y8-82521-51	12FT PIGTAIL BUS FAISCEAU (L: 12FT.)	1				UR UR





FIG. 5 CL5 DISPLAY

CL5 AFFICHAGE

[illegible]



PIECES OPTIONNELLES 1

8




FIG. 7 OPTIONAL PARTS 2

PIECES OPTIONNELLES 2

REF. NO.	PART NO. N° PIECES	DESCRIPTION	QTY					REMARKS
1	6JM-W82A0-00	ELECTRIC UNIT	1					
2	6JM-82361-00	UNITE DE ELECTRIQUE	2					
3	6EX-8195A-00	.CLAMP, CORD	1					
4	67F-82151-30	.COLLIER, CORDON	2					
5	67F-82151-20	.RELAY ASSY	2					
		.RELAIS COMPLET						
		.FUSE (3A)						
		.FUSIBLE (3A)						
		.FUSE (5A)						
		.FUSIBLE (5A)						
6	67F-82151-40	.FUSE (10A)	2					
		.FUSIBLE (10A)						
7	67F-82151-10	.FUSE (30A)	2					
		.FUSIBLE (30A)						
8	6JM-82151-00	.FUSE (30A)	2					
		.FUSIBLE (30A)						
9	6EX-2812A-00	.PULLER, FUSE	1					
		.TENDEUR, FUSIBLE						
10	67F-82151-10	.FUSE (30A)	2					
		.FUSIBLE (30A)						
11	63P-81950-00	.RELAY ASSY	1					
		.RELAIS COMPLET						

NUMERICAL INDEX
INDEX NUMERIQUE

PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.	PART NO. N° PIECES	REF. NO.
6JM-12692-00-P0	2 - 6	6X9-8252H-00	4 - 16	6Y8-85371-01	3 - 9						
6YM-22480-00	5 - 2	6Y8-82553-01	3 - 11		4 - 9						
6EX-2812A-00	7 - 9		3 - 21	6X9-8591T-12	3 - 14						
6JM-42794-00	1 - 3		4 - 11	6X9-8591T-22	4 - 14						
6JM-42794-10	1 - 4	6Y8-82553-11	3 - 21	6YM-87278-00	5 - 6						
65W-45251-00	2 - 2	6Y8-82553-21	3 - 21	6X9-88107-00	3 - 15						
6JM-45985-00-P0	2 - 13	6Y8-82553-31	3 - 21		4 - 15						
6JM-48205-01	3 - 1	6Y8-82553-41	3 - 21	6JM-W2810-00	2 - 19						
6JM-48207-01	4 - 1	6Y8-82553-50	3 - 21	6JM-W4260-00-P0	1 - 1						
6JM-482A0-01	3 - 4	6X9-8255H-00	3 - 17	6JM-W4272-00	6 - 6						
	4 - 4		4 - 17	6JM-W450A-00-P0	2 - 1						
6JM-615A0-00	3 - 2	6Y8-82582-11	3 - 13	6JM-W511A-00-P0	2 - 14						
	4 - 2		4 - 13	6JM-W82A0-00	7 - 1						
6Y8-81920-01	3 - 8	6GR-8258A-00	3 - 20	90101-06020	2 - 5						
	4 - 8	6X6-8258A-01	3 - 19	90101-08M88	2 - 15						
6Y8-81920-11	3 - 18		4 - 19	90152-05M02	2 - 7						
	4 - 18	6GR-8258A-10	4 - 20	90171-10M01	2 - 9						
63P-81950-00	7 - 11	6X6-8258A-11	3 - 19	90185-08057	2 - 17						
6EX-8195A-00	7 - 3		4 - 19	90201-08MA4	2 - 18						
6AH-81996-00	1 - 2	6X6-8258A-21	3 - 19	90201-10M01	2 - 10						
6E5-82148-00	2 - 3		4 - 19	90201-17M00	2 - 8						
6JM-82151-00	7 - 8	6X6-8258A-31	3 - 19	92990-08600	2 - 16						
6G1-82151-01	3 - 6		4 - 19	92990-10100	2 - 12						
	4 - 6	6GR-8258A-40	3 - 20	92995-10600	2 - 11						
67F-82151-10	7 - 7	6X6-8258A-41	3 - 19	97E95-06510	2 - 4						
	7 - 10		4 - 19								
67F-82151-20	7 - 5	6GR-8258A-50	4 - 20								
67F-82151-30	7 - 4	6X6-8258A-51	3 - 19								
67F-82151-40	7 - 6		4 - 19								
6JM-82212-00	6 - 3	6GR-8258A-60	4 - 20								
6JM-82212-10	6 - 4	6X6-8258A-61	3 - 19								
6JM-82223-10	6 - 1		4 - 19								
6JM-82223-20	6 - 2	6X6-8258A-71	3 - 19								
6JM-82224-50	6 - 5		4 - 19								
6JM-82361-00	7 - 2	6X6-8258A-81	3 - 19								
6JM-82386-00	3 - 3		4 - 19								
	4 - 3	6X6-8258A-91	3 - 19								
6Y8-82521-01	3 - 22		4 - 19								
	4 - 21	6YM-83512-00	5 - 5								
6Y8-82521-11	3 - 22	6Y9-83553-00	3 - 10								
	4 - 21		4 - 10								
6Y8-82521-21	4 - 21	6YM-83553-00	3 - 7								
6Y8-82521-31	3 - 12		4 - 7								
	4 - 12	6Y8-83553-02	3 - 5								
	4 - 21		4 - 5								
6Y8-82521-41	4 - 21	6YM-83710-13	5 - 1								
6Y8-82521-51	4 - 21	6YM-83956-00	5 - 3								
6X9-8252H-00	3 - 16	6YD-83957-00	5 - 4								